




## Model 46010 & 46020 Series

### PAR-MAX™ 2 Automatic Water Pressure Pump and General Purpose Pump FEATURES

- Self-Priming
- Run Dry
- Super Quiet
- Smooth Flow
- Low Current Draw
- Extra Low Profile
- Easy to Install
- 1/2" (13 mm) and 1/2" threaded Hose Adaptors included
- Complies with USCG Regulation 183.410 and ISO 8846 MARINE for Ignition Protection
- Pumps comply with BSEN 50081-2 and 89/336/EEC Electromagnetic Compatibility requirements and are **CE** marked.

### SPECIFICATIONS

<b>Pump Design:</b>	Dual Chamber Diaphragm
<b>Pump Drive:</b>	Ball/Sleeve Bearing
<b>Suction Lift:</b>	Self-priming to 4 ft (1.2 m)
<b>Ports:</b>	Threaded, 3/8" NPT Female
<b>Motor:</b>	Permanent Magnet
<b>Weight:</b>	3.2 lb (1.5 kg)
<b>Dimensions:</b>	8.2" L x 3.25" W x 3.75" H (206 mm) x (83 mm) x (95 mm)



Model: 46010 & 46020 Series

### PAR-MAX 2 46010

The PAR-MAX 2 automatic water system pump (46010) is designed for self-contained RVs and pleasure boats with multi-fixture water systems. The system is automatic when a faucet is opened, the pump instantly begins operation to provide a constant flow from tank to faucet. Closing the faucet automatically discontinues pump operation.



### PAR-MAX 2 46020

The 46020 is a non-switched pump. The pump will not turn off automatically. It is recommended you utilize a "lighted" on-off switch so that the pump is turned off when not in use. The pump is able to run dry (no liquid) for extended periods with no damage to the pump, however this could cause needless battery drain.

### PUMP PERFORMANCE / ELECTRICAL SPECIFICATIONS

VARIATIONS MODEL	VOLTAGE	GPM/LPM	PRESSURE (bar)		AMP DRAW @10PSI	FUSE SIZE
			CUT-IN	CUT-OUT		
46010-2900	12 Vdc	2.3 / 8.7	20 (1.4)	40 (2.8)	6	8
46010-2901	24 Vdc	2.3 / 8.7	20 (1.4)	40 (2.8)	3	5
46010-2910	12 Vdc	2.3 / 8.7	10 (0.7)	20 (1.4)	6	8
46010-2911	24 Vdc	2.3 / 8.7	10 (0.7)	20 (1.4)	3	5
46020-2900	12 Vdc	2.3 / 8.7	no switch		6	8
46020-2901	24 Vdc	2.3 / 8.7	no switch		3	5

## INSTALLATION



### MOUNTING

The PAR-MAX 2 pump is self-priming and may be located above or below the fresh water tank in a dry location. To vertically mount this unit, it is best to do so with the motor on top. This will prevent water dripping on motor in the event of a leak.

Place pump on a solid surface and secure with the three mounting screws being careful not to compress the rubber grommets which act as shock absorbers.

### PLUMBING

Flexible potable water hose is recommended instead of rigid piping at pump. If you choose to use copper, provide a short length of hose between copper pipe and the pump to avoid noise and vibration. Use clamps at both ends of hose to prevent air leaks into the water line. NOTE: Intake hose must be minimum 1/2" (13 mm) ID reinforced hose. Main distribution line from pump should also be 1/2" (13 mm) ID with branch and individual supply lines to outlet no smaller than 3/8" (10 mm). Select two of the port adaptors supplied to match your plumbing system. Do not overtighten adaptors - hand tighten only. A Jabsco "Pumpgard" 36400-0000 in line strainer should be installed between pump and tank to keep debris out of system. Fresh water tank must be vented. The pump inlet and outlet hoses may be wrapped with foam rubber to prevent unnecessary noise from hydraulic vibrators. Avoid any kinks or fittings which could cause excessive restrictions. Remember to periodically clean faucet screens. Water purifiers or filters usually create back-pressure and should be on separate feed.

**⚠ WARNING** Fire hazard. Wiring must comply with applicable electrical standards and include a properly sized fuse or circuit breaker. Improper wiring can cause a fire resulting in injury or death.

IF YOU ARE NOT FAMILIAR WITH APPLICABLE ELECTRICAL STANDARDS, HAVE THE UNIT INSTALLED BY A QUALIFIED ELECTRICIAN.

**⚠ WARNING** Explosion hazard. Do not pump gasoline or other flammable liquids. To do so can cause an explosion resulting in injury or death.

### WIRING

The pump should be wired in a dedicated circuit independent of all other accessories. Connect the red wire on the pressure switch to an overload protected switch or breaker panel with a breaker (fuse) of the correct amp rating determined from the electrical specification chart. Connect the motor's black wire lead to battery negative.

Select wire size from chart below. Use total length of wire from electrical source to pump and return. Chart allows for 3% voltage drop. If in doubt, use next larger wire size.


TOTAL LENGTH IN FEET	0-20 (0-6m)	20-35 (6-11m)	35-55 (11-17m)
12 Volt	#14 AWG (2.5 mm <sup>2</sup> )	#12AWG (4 mm <sup>2</sup> )	#10AWG (6 mm <sup>2</sup> )
24 Volt	#16 AWG (1.5 mm <sup>2</sup> )	#14AWG (2.5 mm <sup>2</sup> )	#12AWG (4 mm <sup>2</sup> )

After installation, check the voltage at the pump motor. Voltage should be checked when pump is operating. Full voltage must be available at the pump motor at all times.

### OPERATION

1. Check level of water in tank.
2. Open all faucets hot and cold.
3. Switch pump to on position and wait for hot water tank and water lines to fill.
4. Close each faucet as flow becomes steady and free of air (close cold water first). Pump should shut off soon after closing last faucet.
5. Pump is now ready for automatic operation. It will start when faucet is opened and stop when faucet is closed.
6. If pump will be inoperative for a considerable length of time, turn off power to pump and relieve the water pressure by opening a faucet.

**⚠ CAUTION** Motor case will get hot. Prolonged contact during operation may cause a burn.



## DISASSEMBLY

### Pressure Switch

1. Remove switch (9). Disconnect switch wires.
2. Loosen four pump head screws and carefully remove upper housing assembly (1).

### Upper Housing

Follow steps 1 and 2

3. Inspect check valve (2) for debris.
4. Reassemble new upper housing (1).

### Check Valve Assembly

Follow steps 1 and 2

3. Replace check valve (2).
4. Reassemble upper housing (1).

### Lower Housing, Diaphragm, Motor

Follow steps 1 and 2, then remove 2 recessed screws.

3. Rotate lower housing (4) so drain notch opening on lower housing near baseplate exposes set screw which holds bearing housing to shaft.
4. Loosen this set screw by inserting wrench 1/8" Allen wrench into drain notch opening. Then, slide lower housing (4) off motor shaft.

### Diaphragm continued

5. Loosen two cam piston screws with Phillips head screwdriver and pull apart cam from inner pistons. (Pistons should always be replaced when a new diaphragm is installed.)

### Motor continued

5. Replace motor

## REASSEMBLY

### Motor

1. Reassemble lower housing assembly (4) to motor. (Follow steps 4 to 10.)

### Diaphragm

2. Lower housing is assembled with:
  - Flat side of diaphragm and outer pistons facing motor
  - Hex stem of inner pistons must be aligned into hex holes in outer pistons (4).
  - Outer pistons must be aligned with alignment slots on cam assembly making sure screw holes align in cam assembly, otherwise diaphragm will leak.
3. Tighten cam piston screws partially, center piston in diaphragm, then tighten screws securely (18 in. lbs. torque).

### Lower Housing

4. Reassemble lower housing assembly (4) to motor.
5. Retighten set screw securely. Set screw head must be positioned facing motor covering seam (indentation). (Positioning of this screw is critical to avoid misalignment and subsequent diaphragm damage.)

### Upper Housing, Check Valve

6. Reassemble upper housing (1).
7. Properly seat O-Ring in check valve assembly (2) and check if ferrules and screen are in place on upper housing (1).
8. Install check valve (2) into upper housing (1) and push in.
9. Assemble onto lower housing (4), align 4 screws onto motor by rotating lower housing (4) if necessary.
10. Tighten screws evenly to 30 in. lbs. torque.

### Pressure Switch

1. Place switch against front of pump (9), insert screws and take care not to cross thread or strip out threads in housing.
2. Reconnect wires.

## PUMP SERVICE PARTS

KEY	DESCRIPTION	46010-2900	46010-2901	46010-2910	46010-2911	46020-2900	46020-2901	46030-2900
7	Motor Kit, 12Vdc CE	18753-0640		18753-0640		18753-0640		18753-0651
7	Motor Kit, 24Vdc CE		18753-0641		18753-0641		18753-0641	
2,3,5	Service Kit	18753-0642	18753-0642	18753-0642	18753-0642	18753-0642	18753-0642	18753-0642
9	Switch Kit, 40 psi	18753-0644	18753-0644					18753-0650
9	Switch Kit, 20 psi			18753-0650	18753-0650			

## PORT CONNECTORS

PART NUMBER	PUMP CONNECTION		PLUMBING CONNECTION
18753-0645	3/8" NPT (m)	x	3/8" Hose Barb 90° Elbow
18753-0646	3/8" NPT (m)	x	3/8" Hose Barb Straight
18753-0647	3/8" NPT (m)	x	1/2" Hose Barb 90° Elbow
18753-0648	3/8" NPT (m)	x	1/2" Hose Barb Straight
18753-0649	3/8" NPT (m)	x	1/2"-14 (Qest) Straight Pipe

## TROUBLESHOOTING

All lights are thoroughly inspected before shipping and are warranted to operate within specifications. If light does not operate correctly, check fuse and wire harness connections before proceeding.

Problem	Solution
PULSATING FLOW - PUMP CYCLES ON AND OFF	Restricted pump delivery. Check discharge lines, fittings and valves for clogging or undersizing.
FAILURE TO PRIME - MOTOR OPERATES, BUT NO PUMP DISCHARGE	<ul style="list-style-type: none"> <li>• Restricted intake or discharge line.</li> <li>• Air leak in intake line.</li> <li>• Punctured pump diaphragm</li> <li>• Debris under flapper valves</li> <li>• Crack in pump housing</li> </ul>
MOTOR FAILS TO TURN ON	<ul style="list-style-type: none"> <li>• Loose wiring connection</li> <li>• Pump circuit has no power</li> <li>• Blown fuse</li> <li>• Pressure switch failure</li> <li>• Defective motor</li> </ul>
PUMP FAILS TO TURN OFF AFTER ALL FIXTURES ARE CLOSED.	<ul style="list-style-type: none"> <li>• Empty water tank</li> <li>• Punctured pump diaphragm</li> <li>• Discharge line leak</li> <li>• Defective pressure switch</li> <li>• Insufficient voltage to pump</li> <li>• Debris under flapper valves</li> </ul>
LOW FLOW AND PRESSURE	<ul style="list-style-type: none"> <li>• Air leak at pump intake</li> <li>• Accumulation of debris inside pump and plumbing</li> <li>• Worn pump bearing (excessive noise)</li> <li>• Punctured pump diaphragm</li> <li>• Defective motor</li> </ul>

## WINTERIZING YOUR WATER SYSTEM

To winterize, it is necessary to drain the water from the entire water system. Blowing into the lines to remove the water from your water system is not satisfactory due to the check valve mechanism built into the pump.

Follow these steps to remove all water from your water system:

1. Drain water by opening tank drain, or open a fixture and allow pump to operate until tank is dry.
2. Open the lowest outlet in water system to drain lines.
3. To remove any remaining water (about a cup), remove outlet hose on pump and activate pump. To blow out lines, attach air nozzle where outlet hose was removed. Make sure all fixtures are open before starting.
4. Your water system is now winterized. Don't forget to reattach the outlet hose and close all fixtures.



**DANGER**

**DO NOT USE AUTOMOTIVE TYPE ANTI-FREEZE. IT IS POISONOUS. USE OF THIS TYPE ANTI-FREEZE WILL CAUSE SERIOUS INTERNAL INJURY OR DEATH.**

## JABSCO WATER PRESSURE SYSTEM ACCESSORIES


REGULATOR  
44410-SERIES



ACCUMULATOR TANKS  
30573-0000



PUMP GARD  
36400-SERIES



Jabsco



**ITT Industries**  
Engineered for life

U.S.A.  
Jabsco  
1485 Dale Way, P.O. Box 2158  
Costa Mesa, CA 92628-2158  
Tel: (714) 545-8251  
Fax: (714) 957-0609

UNITED KINGDOM  
Jabsco  
Bingley Road, Hoddesdon  
Hertfordshire EN11 0BU  
Tel: +44 (0) 1992 450145  
Fax: +44 (0) 1992 467132

CANADA  
Fluid Products Canada  
55 Royal Road  
Guelph, Ontario N1H 1T1  
Tel: (519) 821-1900  
Fax: (519) 821-2569

JAPAN  
NHK Jabsco Company Ltd.  
3-21-10, Shin-Yokohama  
Kohoku-Ku, Yokohama, 222  
Tel: 045-4758906  
Fax: 045-475-8908

GERMANY  
Jabsco GmbH  
Oststrasse 28  
22844 Norderstedt  
Tel: +49-40-53 53 73-0  
Fax: +49-40-53 53 73-11

THE PRODUCTS DESCRIBED HEREIN ARE SUBJECT TO THE JABSCO ONE YEAR LIMITED WARRANTY, WHICH IS AVAILABLE FOR YOUR INSPECTION UPON REQUEST.