

VL-1504 INSTRUCTIONS

The replacement of VL-1504 Vacuum Breaker Assembly is accomplished as follows:

- * Remove the old assembly.
- * Assure that the machined seat area between the new assembly and the bronze cap casting is clean and free of salt or sand build-up or other debris. Clean or lightly sand this surface if necessary.
- * The new vacuum breaker assembly may not fit as snugly as the old one. This is due to a dimensional change by our supplier of the rubber parts (over which we had no choice or control). A drop of marine caulk on the machined bronze seat will keep the vacuum breaker assembly in place during re-assembly.
- * Screw the cap hand-tight into the vented loop body.

**VL-1504
MEMBRANE
ONLY**

