


BARNES®

INSTALLATION and OPERATION MANUAL Submersible Sewage Ejector

Explosion Proof, Class I, Groups C & D, Division 1



Series: 3XSE-EA

0.75HP, 1150RPM, 60Hz

1.5, 2.0, 3.0HP, 1750RPM, 60Hz

IMPORTANT!

Read all instructions in this manual before operating pump.

As a result of Crane Pumps & Systems, Inc., constant product improvement program, product changes may occur. As such Crane Pumps & Systems reserves the right to change product without prior written notification.

CRANE

A Crane Co. Company

PUMPS & SYSTEMS

420 Third Street
Piqua, Ohio 45356
Phone: (937) 778-8947
Fax: (937) 773-7157
www.cranepumps.com

83 West Drive, Bramton
Ontario, Canada L6T 2J6
Phone: (905) 457-6223
Fax: (905) 457-2650



Form No. 625-01738-Rev. G

TABLE OF CONTENTS

SAFETY FIRST	3
A. PUMP SPECIFICATIONS	4
B. GENERAL INFORMATION	5
C. INSTALLATION	5 - 9
ELECTRICAL DATA	6
D. START-UP OPERATION	9 - 10
E. PREVENTATIVE MAINTENANCE	10
F. SERVICE and REPAIR	10 - 11
G. REPLACEMENT PARTS.....	11
TRUBLE SHOOTING	12
CROSS-SECTION, (Fig. 7).....	13
EXPLODED VIEW, (Fig. 8)	14
PARTS LIST	15 - 18
RETURNED GOODS POLICY.....	19
WARRANTY	20
START-UP REPORT	21 - 22
WARRANTY REGISTRATION	
SPECIAL TOOLS AND EQUIPMENT	
INSULATION TESTER (MEGGER)	
DIELECTRIC TESTER	
SEAL TOOL KIT (see parts list)	

Other brand and product names are trademarks or registered trademarks of their respective holders.

® WARRICK Controls is a registered trademark of Charles F. WARRICK Co.

® Reliance is a registered trademark of Rockwell Automation

® Barnes is a registered trademark of Crane Pumps & Systems, Inc

1983, 1997, 1998, 2002, 1/04, 6/06, 9/06, 2/07

Alteration Rights Reserved

SAFETY FIRST!

Please Read This Before Installing Or Operating Pump.
This information is provided for **SAFETY and to PREVENT EQUIPMENT PROBLEMS**. To help recognize this information, observe the following symbols:



IMPORTANT! Warns about hazards that can result in personal injury or Indicates factors concerned with assembly, installation, operation, or maintenance which could result in damage to the machine or equipment if ignored.

CAUTION ! Warns about hazards that can or will cause minor personal injury or property damage if ignored. Used with symbols below.

WARNING ! Warns about hazards that can or will cause serious personal injury, death, or major property damage if ignored. Used with symbols below.



Hazardous fluids can cause fire or explosions, burnes or death could result.



Extremely hot - Severe burnes can occur on contact.



Biohazard can cause serious personal injury.



Hazardous fluids can Hazardous pressure, eruptions or explosions could cause personal injury or property damage.




Rotating machinery Amputation or severe laceration can result.



Hazardous voltage can shock, burn or cause death.

Only qualified personnel should install, operate and repair pump. Any wiring of pumps should be performed by a qualified electrician.



WARNING ! - To reduce risk of electrical shock, pumps and control panels must be properly grounded in accordance with the National Electric Code (NEC) or the Canadian Electrical Code (CEC) and all applicable state, province, local codes and ordinances.



WARNING! - To reduce risk of electrical shock, always disconnect the pump from the power source before handling or servicing. Lock out power and tag.



WARNING! Operation against a closed discharge valve will cause premature bearing and seal failure on any pump, and on end suction and self priming pump the heat build may cause the generation of steam with resulting dangerous pressures. It is recommended that a high case temperature switch or pressure relief valve be installed on the pump body.



CAUTION ! Never operate a pump with a plug-in type power cord without a ground fault circuit interrupter.



CAUTION! Pumps build up heat and pressure during operation-allow time for pumps to cool before handling or servicing.



WARNING! - **DO NOT** pump hazardous materials (flammable, caustic, etc.) unless the pump is specifically designed and designated to handle them.



Do not block or restrict discharge hose, as discharge hose may whip under pressure.



WARNING! - DO NOT wear loose clothing that may become entangled in the impeller or other moving parts.



WARNING! - Keep clear of suction and discharge openings. **DO NOT** insert fingers in pump with power connected.


Always wear eye protection when working on pumps.



Make sure lifting handles are securely fastened each time before lifting. **DO NOT** operate pump without safety devices in place. Always replace safety devices that have been removed during service or repair. Secure the pump in its operating position so it can not tip over, fall or slide.

DO NOT exceed manufacturers recommendation for maximum performance, as this could cause the motor to overheat.


DO NOT remove cord and strain relief. Do not connect conduit to pump.




WARNING! Cable should be protected at all times to avoid punctures, cut, bruises and abrasions - inspect frequently. Never handle connected power cords with wet hands.



WARNING! To reduce risk of electrical shock, all wiring and junction connections should be made per the NEC or CEC and applicable state or province and local codes. Requirements may vary depending on usage and location.



WARNING! Submersible Pumps are not approved for use in swimming pools, recreational water installations, decorative fountains or any installation where human contact with the pumped fluid is common.



WARNING! Products Returned Must Be Cleaned, Sanitized, Or Decontaminated As Necessary Prior To Shipment, To Insure That Employees Will Not Be Exposed To Health Hazards In Handling Said Material. All Applicable Laws And Regulations Shall Apply.



Bronze/brass and bronze/brass fitted pumps may contain lead levels higher than considered safe for potable water systems. Lead is known to cause cancer and birth defects or other reproductive harm. Various government agencies have determined that leaded copper alloys should not be used in potable water applications. For non-leaded copper alloy materials of construction, please contact factory.



IMPORTANT! - Crane Pumps & Systems, Inc. is not responsible for losses, injury, or death resulting from a failure to observe these safety precautions, misuse or abuse of pumps or equipment.

SECTION B: GENERAL INFORMATION

B-1) To the Purchaser:

Congratulations! You are the owner of one of the finest pumps on the market today. CP&S pumps are products engineered and manufactured of high quality components. Over one hundred years of pump building experience along with a continuing quality assurance program combine to produce a pump which will stand up to the toughest applications. This manual will provide helpful information concerning installation, maintenance, and proper service guidelines.

B-2) Receiving:

Upon receiving the pump, it should be inspected for damage or shortages. If damage has occurred, file a claim immediately with the company that delivered the pump. If the manual is removed from the packaging, do not lose or misplace.

B-3) Storage:

Short Term- CP&S Pumps are manufactured for efficient performance following short inoperative periods in storage. For best results, pumps can be retained in storage, as factory assembled, in a dry atmosphere with constant temperatures for up to six (6) months.

Long Term- Any length of time exceeding six (6) months, but not more than twenty-four (24) months. The unit should be stored in a temperature controlled area, a roofed over walled enclosure that provides protection from the elements (rain, snow, wind-blown dust, etc.), and whose temperature can be maintained between +40 deg. F and +120 deg. F. (4.4 - 49°C). Pump should be stored in its original shipping container. On initial start up, rotate impeller by hand to assure seal and impeller rotate freely. If it is required that the pump be installed and tested before the long term storage begins, such installation will be allowed provided:

- 1.) The pump is not installed under water for more than one (1) month.
- 2.) Immediately upon satisfactory completion of the test, the pump is removed, thoroughly dried, repacked in the original shipping container, and placed in a temperature controlled storage area.

B-4) Service Centers:

For the location of the nearest Barnes Service Center, check your Barnes representative or Crane Pumps & Systems, Inc., Service Department in Piqua, Ohio, telephone (937) 778-8947 or Crane Pumps & Systems Canada, in Brampton, Ontario, (905) 457-6223.

SECTION C: INSTALLATION

C-1) Location:

These self-contained pumping units have motors that are Underwriters Laboratory Listed for Class I, Groups C & D, Division 1 locations and are recommended for use in a sump, lift station or basin. This pump is designed for submerged continuous duty (15 minutes duty in air at nameplate horsepower), pumping sewage, effluent, wastewater or other non explosive or non corrosive liquids not above 104°F (40°C). Never install the pump in a trench, ditch or hole with a dirt bottom; the legs will sink into the dirt and the suction will become plugged.

C-1.1) Submergence:

It is recommended that the pump be operated in the submerged condition and the sump liquid level should never be less than dimension "A" in Figure 1. The time required to draw the well down from top of motor to the minimum submergence level should not be greater than 15 minutes.

NOTE: Outer shaft seal must be in liquid when motor is operated, whether motor is submerged or in air.




FIGURE 1

C-2) Discharge:

Discharge piping should be as short as possible. Both a check valve and a shut-off valve are recommended for each pump being used. The check valve is used to prevent backflow into the sump. Excessive backflow can cause flooding and/or damage to the pump. The shut-off valve is used to stop system flow during pump or check valve servicing.



WARNING ! - These pumps are suitable for application in CLASS I, GROUPS C & D, HAZARDOUS LOCATIONS and require a non-sparking break away fitting. Failure to use the non-sparking BAF voids warranty.

Barnes supplies a Non-Sparking break away fitting discharge system designed to allow the submersible wastewater pump to be installed or removed without requiring personnel to enter the wet well. Place the Break Away Fitting (BAF) in position. Temporarily secure the guide rails in the upper mounting brackets and locate the base elbow on the bottom of the wet well. Level the base elbow with grout and/or shims. Install the intermediate support brackets, if required. Make sure the rails are in a true vertical position so the pump will clear the access opening and will slide freely down the rails into place on the discharge base elbow. once the rails are in proper alignment, bolt the base elbow into the floor of the station and connect the discharge pipe to the elbow. Connect the movable portion and other supplied fittings of the BAF onto the pump and lower into wet well. See the Break Away Fitting manual for more information.

If a rigid conduit is used to install the pump it must meet Class I, Division 1 requirements of the National Electrical Code. Conduit must be stainless steel or coated metal, resistant to sewage water.

C-3) Liquid Level Controls: Intrinsically Safe



WARNING! - Level control floats used within the hazardous location, must be in an intrinsically safe control circuit suitable for use in CLASS I, GROUPS C & D, HAZARDOUS LOCATIONS.

The level controls are to be supported by a mounting bracket that is attached to the sump wall, cover or junction box. Cord grips are used to hold the cords in place on the mounting bracket. The control level can be changed by loosening the grip and adjusting the cord length as per the plans and specifications. Be certain that the level controls cannot hang up or foul in it's swing and that the entire pump is still submerged when the level control is in the "Off" mode.

A Warrick Control® intrinsically safe relay, Series 27, is an acceptable panel mounted relay, providing the relay is properly installed and maintained. The primary (A.C. supply line) circuit is not intrinsically safe, therefore the relay must be located in a "SAFE" location (a place that is not classified as a hazardous location). The secondary circuit is intrinsically safe, however, any splice must be made in a "SAFE" location and any control cord that is cut or damaged must be replaced immediately.

C-3.1) Level Control Float System:

It is recommended to use a two float, on and off, level control system. An additional float, incorporated with an alternator switching system will be required for a duplex system. A high level alarm may be required to alert maintenance personnel. A low level cut off may be required to provide system shutdown if the main level control system malfunctions. The off or low level float should be positioned so that the liquid level never drops below the minimum submergence level.

C-4) Electrical Connections:



WARNING! - all model pumps and control panels must be properly grounded per the NATIONAL ELECTRIC CODE or CANADIAN ELECTRIC CODE, STate, Province and local codes. Improper grounding voids warranty.

All electrical controls and motor starting equipment must be installed outside the hazardous area unless approved explosion proof controls are used.

C-4.1) Power/Control Cords:

The cord assembly mounted to the pump must not be modified in any way except for shortening to a specific application. Any splice between the pump and the control panel must be made in accordance with the electric codes. It is recommended that a junction box (if used) **with seal fittings** be mounted outside the sump or be of at least Nema 7 (EEMAC-7) explosion proof construction if located within the wet well. A UL listed seal fitting **MUST** be used in conduit leaving the hazardous location. Do not use the power or control cords to lift pump. **NOTE:** The white wire is **NOT** a neutral or ground lead, but a power carrying conductor.

C-4.2) Wire Size:


If additional cable is required consult a qualified electrician for proper wire size. See table for further electrical information.

MODEL NO	"A" DIM	HP	VOLT/ Ph	Hz	RPM (Nom)	NEMA START CODE	FULL LOAD AMPS	LOCKED ROTOR AMPS	CORD SIZE	CORD TYPE	CORD O.D. ± .02 (.5) in (mm)	WINDING RESISTANCE MAIN
3XSE716EA	31.69	.75	115/1	60	1150	K	15.2	52.6	12/4	SOW	0.675 (17)	2.58
3XSE706EA	31.69	.75	200/1	60	1150	K	8.7	30.2	12/4	SOW	0.675 (17)	
3XSE726EA	31.69	.75	230/1	60	1150	K	7.6	26.3	12/4	SOW	0.675 (17)	10.12
3XSE766EA	31.69	.75	200/3	60	1150	L	2.9	15.4	14/4	SOW	0.590 (15)	
3XSE736EA	31.69	.75	230/3	60	1150	L	2.6	13.4	14/4	SOW	0.590 (15)	
3XSE746EA	31.69	.75	460/3	60	1150	L	1.3	6.7	14/4	SOW	0.590 (15)	23.6
3XSE1504EA	31.69	1.5	200/1	60	1750	K	13.2	66.7	14/4	SOW	0.590 (15)	.98/4.0
3XSE1524EA	32.69	1.5	230/1	60	1750	K	11.5	58.0	14/4	SOW	0.590 (15)	4.82
3XSE1564EA	31.69	1.5	200/3	60	1750	K	6.9	34.9	14/4	SOW	0.590 (15)	2.56
3XSE1534EA	31.69	1.5	230/3	60	1750	K	6.0	30.4	14/4	SOW	0.590 (15)	3.39
3XSE1544EA	31.69	1.5	460/3	60	1750	K	3.0	15.2	14/4	SOW	0.590 (15)	13.59
3XSE2004EA	32.19	2.0	200/1	60	1750	J	16.1	79.3	12/4	SOW	0.675 (17)	.68/2.7
3XSE2024EA	32.19	2.0	230/1	60	1750	K	14.0	69.0	12/4	SOW	0.675 (17)	3.90
3XSE2064EA	31.69	2.0	200/3	60	1750	K	8.2	50.3	14/4	SOW	0.590 (15)	.86
3XSE2034EA	31.69	2.0	230/3	60	1750	K	7.2	43.8	14/4	SOW	0.590 (15)	2.30
3XSE2044EA	31.69	2.0	460/3	60	1750	K	3.6	21.9	14/4	SOW	0.590 (15)	9.20
3XSE3004EA	32.84	3.0	200/1	60	1750	J	23.0	111.5	10/4	SOW	0.735 (19)	.45/1.7
3XSE3024EA	32.84	3.0	230/1	60	1750	J	20.0	97.0	10/4	SOW	0.735 (19)	2.97
3XSE3064EA	31.69	3.0	200/3	60	1750	H	11.9	58.9	14/4	SOW	0.590 (15)	.61
3XSE3034EA	31.69	3.0	230/3	60	1750	H	10.4	51.3	14/4	SOW	0.590 (15)	1.62
3XSE3044EA	31.69	3.0	460/3	60	1750	H	5.2	25.6	14/4	SOW	0.590 (15)	6.48

Winding Resistance ± 5%. Winding resistance measured in OHMS @ 25°C (Between Lines). Pump rated for operation at ± 10% voltage at motor. Moisture and Temperature sensor cord for all models is 18/5 SOW, 0.485 (12.4mm) ± .02 (.51mm) O.D.


SINGLE PHASE, 200-230 VOLT AC

Power Cable	Motor Lead Number
Green (Ground)	Green
White	4 & 8
Red	5
Black	1




THREE PHASE, 200-230 VOLT AC

Power Cable	Motor Lead Number
Green (Ground)	Green
White	2 & 8
Red	3 & 9
Black	1 & 7
	4, 5 & 6 Together




THREE PHASE, 460 VOLT AC

Power Cable	Motor Lead Number
Green(Ground)	Green
Black	1
White	2
Red	3
	4 & 7 Together
	5 & 8 Together
	6 & 9 Together





MOISTURE AND TEMPERATURE SENSORS

Control Cable	Lead Number
Black	P1 (Temperature Sensor)
White	P2 (Temperature Sensor)
Red	W1 (Moisture Sensor)
Orange	W2 (Moisture Sensor)
Green	Ground



TYPICAL THERMAL PROTECTION WIRING DIAGRAM





WARRANTY NOTE:

Both the temperature sensor and moisture detection system must be connected to the motor circuitry such that the motor will be de-energized or sound alarm if excessive motor temperatures are reached and/or if water is detected in the seal chamber and/or motor chamber. Failure to have the above mentioned systems installed and operative, nullifies warranty.

C-4.3) Overload Protection:

The normally closed (N/C) thermal sensor is embedded in the motor windings and will detect excessive heat in the event an overload condition occurs which will then trip and stop the pump. The thermal sensor leads marked P1 and P2 **MUST** be connected in series with the stop button of the pilot circuit of the magnetic motor controller located in the control panel so that the thermostat will open the circuit before dangerous temperatures are reached. A manual momentary start switch is required to prevent the automatic restarting of the motor when the thermostat resets. For a typical wiring diagram, refer to Fig. 2. In the event of an overload, the source of this condition should be determined and rectified before the pump is put back into normal operation. **DO NOT LET THE PUMP CYCLE OR RUN IF AN OVERLOAD CONDITION OCCURS !**

If current through the temperature sensor exceeds the values listed, an intermediate control circuit relay must be used to reduce the current or the sensor will not work properly.

TEMPERATURE SENSOR ELECTRICAL RATINGS		
Volts	Continuous Amperes	Inrush Amperes
110 - 120	3.00	30.0
220 - 240	1.50	15.0
440 - 480	0.75	7.5

C-4.4 Moisture Sensors:

A normally open (N/O) detector is installed in the pump seal chamber, which will detect any moisture present, and a continuity test resistor built into the motor. The test resistor is rated 1 watt at 330K ohms. The moisture sensors **MUST** be connected to moisture detector control, which includes a continuity test circuit, see Fig. 3 for typical wiring diagram. The normally closed (N/C) contact of the moisture detector **MUST** be connected in series with the stop button of the pilot circuit of the magnetic motor controller. A Warrick moisture detection control, Type 2800 is an acceptable control if properly installed and maintained. Wiring must be provided from the moisture detector sensor probe leads of the motor designated W1 and W2 to terminals 9 and 10 of the 2800-XXX control. Terminal pair 1-2 must be continuously energized from an A-C supply line of electrical characteristics shown on the data table. In the event of moisture detection, the pump should be pulled and the source of the failure located and repaired. **IF MOISTURE DETECTION HAS OCCURRED, SCHEDULE MAINTENANCE AS SOON AS POSSIBLE !**

C-4.5) Control Panel and Electrical System:

The control panel and the electrical system **MUST** be properly designed and wired to include at least, but not limited to the following;

- a. Proper grounding per NEC.
- b. A temperature sensing circuit (see Fig. 2A & B)
- c. A moisture detection circuit with continuity test circuit (see Fig. 3)
- d. An intrinsically safe level control system.
- e. A main power manual disconnect and lock out.
- f. A motor starter and overload system.
- g. Single phase only, requires a capacitor power pack (see Fig. 2B).

Control panels for single phase pumps **MUST** be purchased from the factory and it is advisable that all three phase control panels are also purchased from the factory.

SECTION: D START-UP OPERATION

D-1) Check Voltage and Phase:

Before operating pump, compare the voltage and phase information stamped on the pump's identification plate to the available power.

D-2) Check Pump Rotation:

Before putting pump into service for the first time, the motor rotation must be checked. Improper motor rotation can result in poor pump performance and can damage the motor and/or pump. To check the rotation, suspend the pump freely, momentarily apply power and observe the "kickback". "Kickback" should always be in a counter-clockwise direction as viewed from the top of the pump motor housing.

D-2.1) Incorrect Rotation for Three-Phase Pumps:

In the event that the rotation is incorrect for a three-phase installation, interchange any two power cable leads at the control box. **DO NOT** change leads in the cable housing in the motor. Recheck the "kickback" rotation again by momentarily applying power.

D-2.2) Incorrect Rotation for Single-Phase Pumps:

In the unlikely event that the rotation is incorrect for a single phase pump, contact a Barnes Service Center.

D-2.3) Test Procedure For Moisture Sensor Control:

With a Warrick moisture detection control, type 2800, a normally closed push button and neon indicating lamp is provided as a means of checking the moisture sensing components. When the push button is depressed, the indicating lamp will be illuminated to indicate (A) power is supplied to the control, (B) the control is operative, and (C) wiring to the moisture sensing probes in the motor is intact. This procedure should be performed periodically to confirm integrity of the circuit.

D-3) Start-Up Report:

Included at the end of this manual are two start-up report sheets, these sheets are to be completed as applicable. Return one copy to Barnes and store the second in the control panel or with the pump manual if no control panel is used. It is important to record this data at initial start-up since it will be useful to refer to should servicing the pump be required in the future.

D-3.1) Identification Plate:

Record the numbers from the pump's identification plate on both START-UP REPORTS provided at the end of the manual for future reference.

D-3.2) Insulation Test:

Before the pump is put into service, an insulation (megger) test should be performed on the motor. The resistance values (ohms) as well as the voltage (volts) and current (amps) should be recorded on the start-up report.

D-3.3) Pump-Down Test:

After the pump has been properly wired and lowered into the basin, sump or lift station, it is advisable to check the system by filling with liquid and allowing the pump to operate through its pumping cycle. The time needed to empty the system, or pump-down time along with the volume of water, should be recorded on the start-up report.

SECTION E: PREVENTATIVE MAINTENANCE

As the motor is Air-filled, no lubrication or other maintenance is required, and generally Barnes pumps will give very reliable service and can be expected to operate for years of normal sewage pumping without failing. However, as with any mechanical piece of equipment a preventive maintenance program is recommended and suggested to include the following checks:

- 1) Test moisture detector control "Test Switch" for continuity of circuit. Water in the seal chamber will energize a seal leak warning light at the control panel. This is a warning light only and does not stop the motor. It indicates the seal has leaked and must be repaired. This should be done within 2 or 3 weeks to prevent further damage. See section D-2.2.
- 2) Inspect impeller and body for excessive build-up or clogging and repair as required per section F-1.
- 3) Inspect outer shaft seal and replace as required per section F-2.
- 4) Check motor for ground leakage and proper amp draw. Motor and inner seal repair per section F-3.

SECTION F: SERVICE AND REPAIR

NOTE: All item numbers in () refer to Figures 7 & 8.



WARNING ! - Electrical power to the pump motors must be disconnected and locked out to prevent any dangerous electrical hazards or personnel danger before any service work is done to the pump.



CAUTION ! - Operating pump builds up heat and pressure; allow time for pump to cool to room temperature before handling or servicing.

F-1) Impeller and Volute Service:

F-1.1) Disassembly and Inspection:

To clean out the volute (3), or clean out or replace impeller (4), disconnect power, remove cap screws (1) and vertically lift motor assembly from the volute (3). Clean out the volute, if necessary. Clean and examine impeller (4) for pitting or wear. To remove Impeller (4), remove socket head screw (8) and washer (9).

The impeller is keyed onto the shaft with a square key (21-supplied with motor) and to remove, pull impeller straight off the shaft using a wheel puller if required. Before reinstallation, check the motor shaft and impeller bore for damage.

F-1.2) Reassembly:

Apply thread locking compound to cap screws (5), set legs (16) into place on volute (3), place washers (15) on cap screws (5) that are used on legs (16) and torque cap screws (5) into volute (3) to 92ft. lbs. Place adapter plate (2) on shaft end of motor (17). Install impeller (4) by applying a thin film of oil to motor shaft and slide impeller straight onto shaft, keeping keyways lined up. Drive key (21) into keyway. Locate impeller washer (9) on shaft, apply thread locking compound to socket head screw (8) threads, thread into shaft and torque to 35 ft. lbs. Rotate impeller to check for binding. Install impeller, adapter plate and motor assembly onto volute (3). Apply thread locking compound to threads of each cap screw (1) and insert into motor, adapter plate and volute assembly and torque to 24 ft. lbs. Check for free rotation of motor and impeller.

F-2) Outer Shaft Seal Service:



CAUTION ! - Handle seal parts with extreme care. DO NOT scratch or mar lapped surfaces.

F-2.1) Disassembly and Inspection:

To expose outer shaft seal (20) for examination, remove Impeller and Volute per Section F-1.1. Set motor assembly (17) in the up position to prevent loss of oil. Remove snap ring from motor shaft, then retaining ring (20D), spring (20C) and rotating member (20B) from shaft, See Fig. 4. Examine all seal parts and especially contact faces.




FIGURE 4

Inspect seal for signs of wear such as uneven wear pattern on stationary members, chips and scratches on either seal face. **DO NOT** interchange seal components, replace the entire shaft seal (20). If replacing seal, remove stationary (20A) from mounting plate by prying out with flat screw driver.

F-2.2) Reassembly:

Lightly oil (**DO NOT use grease**) outer surface of stationary member (20A). Press stationary member (20A) firmly into mounting plate using a seal pusher, nothing but the seal pusher is to come in contact with seal face (see Fig. 5).




FIGURE 5

IMPORTANT ! - DO NOT hammer on the seal pusher- it will damage the seal face.

Make sure the stationary member is in straight and that the rubber ring is not out of its groove. Lightly oil (**DO NOT use grease**) shaft and inner surface of bellows on rotating member (20B) see Fig. 6. With lapped surface of rotating member (20B) facing inward toward stationary member (20A), slide rotating member (20B) onto shaft using a seal pusher, until lapped faces of (20A) and (20B) are together. (see Fig. 4).

IMPORTANT ! - It is extremely important to keep seal faces clean during assembly. Dirt particles lodged between these faces will cause the seal to leak.




FIGURE 6

Place spring (20C) over shaft and in place on rotating member (20B), making sure it is seated on retainer and not cocked or resting on bellows tail. Slide retaining ring (20B) over shaft and let rest on spring (20C). Assemble impeller and volute as outlined in paragraph F-1.2.

WARNING ! - DO NOT disassemble the reliance motor in any way, except for outer seal, as this will void warranty.

F-3) Motor & Inner Shaft Seal Service

The XSE Submersible Pump motor is manufactured by Reliance Electric Co. and must be serviced and repaired by Reliance approved service centers only. For lead reconnection information, contact Reliance Electric Co., giving motor serial number.

WARNING ! - These motors are u/l listed for application in CLASS I, GROUPS C & D EXPLOSION PROOF environments. All repairs, other than lead reconnects and outer seal replacement, shall be performed by an authorized RELIANCE SERVICE FACILITY. Any other repairs performed by the customer or NON-RELIANCE Service facilities negates the u/l listing and motor warranty.



SECTION: G REPLACEMENT PARTS

G-1 ORDERING REPLACEMENT PARTS:

When ordering replacement parts, ALWAYS furnish the following information:

1. Pump serial number and date code. (Paragraph G-4)
2. Pump model number. (Paragraph G-3)
3. Pump part number. (Paragraph G-2)
4. Part description.
5. Item part number.
6. Quantity required.
7. Shipping instructions.
8. Billing Instructions.

BARNES	HP.	Volts	Code	Ph.	Hz.
	RPM	FLA	Model No.	2	
	Part No.	3		Serial No.	1
	Impeller Dia.	Max. Liq. Temp.	°C	Ins. Class	

WARNING TO REDUCE RISK OF ELECTRICAL SHOCK DISCONNECT THE PUMP FROM THE POWER SOURCE BEFORE HANDLING OR SERVICING. SEE INSTRUCTION MANUAL FOR PROPER INSTALLATION. SEE WARNING PLATE FOR ADDITIONAL CAUTIONS.

G-2 PART NUMBER:

The part number consists of a six (6) digit number, which appears in the catalog. A one or two letter suffix may follow this number to designate the design configuration. This number is used for ordering and obtaining information.

G-3 MODEL NUMBER:

This designation consists of numbers and letters which represent the discharge size, series, horsepower, motor phase and voltage, speed and pump design. This number is used for ordering and obtaining information.

G-4 SERIAL NUMBER:

The serial number block will consist of a six digit number, which is specific to each pump and may be preceded by a alpha character, which indicates the plant location. This number will also be suffixed with a four digit number, which indicates the date the unit was built (Date Code). **EXAMPLE: A012345 0490.**

Reference the six digit portion (Serial Number) of this number when referring to the product.

TROUBLE SHOOTING

CAUTION ! Always disconnect the pump from the electrical power source before handling.
If the system fails to operate properly, carefully read instructions and perform maintenance recommendations.
If operating problems persist, the following chart may be of assistance in identifying and correcting them:

MATCH "CAUSE" NUMBER WITH CORRELATING "CORRECTION" NUMBER.

NOTE: Not all problems and corrections will apply to each pump model.

PROBLEM	CAUSE	CORRECTION
Pump will not run	<ol style="list-style-type: none"> 1. Poor electrical connection, blown fuse, tripped breaker or other interruption of power, improper power supply. 2. Motor or switch inoperative (to isolate cause, go to manual operation of pump). <ol style="list-style-type: none"> 2a. Float movement restricted. 2b. Switch will not activate pump or is defective. 2c. Defective motor 3. Insufficient liquid level. 	<ol style="list-style-type: none"> 1. Check all electrical connections for security. Have electrician measure current in motor leads, if current is within $\pm 20\%$ of locked rotor Amps, impeller is probably locked. If current is 0, overload may be tripped. Remove power, allow pump to cool, then recheck current. 2a. Reposition pump or clean basin as required to provide adequate clearance for float. 2b. Disconnect level control. Set ohmmeter for a low range, such as 100 ohms full scale and connect to level control leads. Actuate level control manually and check to see that ohmmeter shows zero ohms for closed switch and full scale for open switch. (Float Switch). 2c. Check winding insulation (Megger Test) and winding resistance. If check is outside of range, dry and recheck. If still defective, replace per service instructions.
Pump will not turn off	<ol style="list-style-type: none"> 2a. Float movement restricted. 2b. Switch will not activate pump or is defective. 4. Excessive inflow or pump not properly sized for application. 9. Pump may be airlocked 14. H-O-A switch on panel is in "HAND" position 	<ol style="list-style-type: none"> 3. Make sure liquid level is at least equal to suggested turn-on point. 4. Recheck all sizing calculations to determine proper pump size. 5. Check discharge line for restrictions, including ice if line passes through or into cold areas. 6. Remove and examine check valve for proper installation and freedom of operation. 7. Open valve.
Pump hums but does not run	<ol style="list-style-type: none"> 1. Incorrect voltage 8. Impeller jammed or loose on shaft, worn or damaged, impeller cavity or inlet plugged. 	<ol style="list-style-type: none"> 8. Check impeller for freedom of operation, security and condition. Clean impeller and inlet of any obstruction. 9. Loosen union slightly to allow trapped air to escape. Verify that turn-off level of switch is set so that the suction is always flooded. Clean vent hole.
Pump delivers insufficient capacity	<ol style="list-style-type: none"> 1. Incorrect voltage. 4. Excessive inflow or pump not properly sized for application. 5. Discharge restricted. 6. Check valve stuck closed or installed backwards. 7. Shut-off valve closed. 8. Impeller jammed or loose on shaft, worn or damaged, impeller cavity or inlet plugged. 9. Pump may be airlocked. 10. Pump running backwards 	<ol style="list-style-type: none"> 10. Check rotation. If power supply is three phase, reverse any two of three power supply leads to ensure proper impeller rotation.. 11. Repair fixtures as required to eliminate leakage. 12. Check pump temperature limits & fluid temperature. 13. Replace portion of discharge pipe with flexible connector. 14. Turn to automatic position. 15. Check for leaks around basin inlet and outlets.
Pump cycles too frequently or runs periodically when fixtures are not in use	<ol style="list-style-type: none"> 6. Check valve stuck closed or installed backwards. 11. Fixtures are leaking. 15. Ground water entering basin. 	
Pump shuts off and turns on independent of switch, (trips thermal overload protector). CAUTION! Pump may start unexpectedly. Disconnect power supply.	<ol style="list-style-type: none"> 1. Incorrect voltage. 4. Excessive inflow or pump not properly sized for application. 8. Impeller jammed, loose on shaft, worn or damaged, impeller cavity or inlet plugged. 12. Excessive water temperature. (internal protection only) 	
Pump operates noisily or vibrates excessively	<ol style="list-style-type: none"> 2c. Worn bearings, motor shaft bent. 5. Debris in impeller cavity or broken impeller 10. Pump running backwards 13. Piping attachments to building structure too rigid or too loose. 	




FIGURE 7




FIGURE 8

**Series: 3XSE-EA, .75HP, 1150RPM
3XSEV-EA, 1.0 - 2.0HP, 1150RPM**

PARTS LIST

ITEM	QTY	DESCRIPTION	PART NO.
1	8	Hex Hd Screw 3/8-16 x 1.75" Lg, Stainless	1-39-1
2	1	Adapter Plate, Cast Iron	4360
3	1	Volute 3XSE	014-00003-101
		3XSEV	014-00003-103

ITEM #4 - IMPELLER, CAST IRON		
IMPELLER DIA.	3XSE - PART NO.	3XSEV - PART NO.
5.00	4366-A-101	4365-A-101
5.12	4366-A-103	4365-A-103
5.25	4366-A-105	4365-A-105
5.37	4366-A-107	4365-A-107
5.50	4366-A-109	4365-A-109
6.62	4366-A-111	4365-A-111
5.75	4366-A-113	4365-A-113
5.87	4366-A-115	4365-A-115
6.00	4366-A-117	4365-A-117 - 1HP
6.12	4366-A-119	4365-A-119
6.25	4366-A-121	4365-A-121
6.37	4366-A-123	4365-A-123
6.50	4366-A-125 - .75HP	4365-A-125 - 1.5HP
6.62	N/A	4365-A-127
6.75	N/A	4365-A-129
6.87	N/A	4365-A-131
7.00	N/A	4365-A-133
7.12	N/A	4365-A-135
7.18	N/A	4365-A-136 - 2HP

5	6	Hex Hd Screw 5/16-18 x .75" Lg, Stainless	1-129-1
8	1	Socket Hd Screw, 3XSE 3/8-16 x 1.00" Lg, Stainless	11-62-1
	1	Socket Hd Screw, 3XSEV 3/8-16 x 1.25" Lg, Stainless	11-63-1
9	1	Impeller Washer, 140 Frame .406 x 1.437	4367-01
12	3Ft	Steel Chain, .250	625-01584
	4Ft	Steel Chain, .312, (2.0HP - 1Ph)	625-01582
13	3	Cold Shut, .312	625-00830
	3	Cold Shut, .375, (2.0HP - 1Ph)	625-00828
14	1	Warning Tag	625-03031
15	6	Lockwasher 5/16" Stainless	20-22-1
16	3	Leg	4321R
17	1	Motor	SEE TABLE 1
20	1	Outer Seal, (Supplied with Motor)	
21	1	Shaft Key, (Supplied with Motor)	

**Series: 3XSE-EA, .75HP, 1150RPM
3XSEV-EA, 1.0 - 2.0HP, 1150RPM**

PUMP MODEL	MOTOR FRAME/ FLANGE	TABLE 1 - MOTOR WITH CABLE
		25FT
3XSE716EA	180/140TY	610-05433-001
3XSE706EA	180/140TY	610-05483-001
3XSE726EA	180/140TY	610-054D3-001
3XSE766EA	180/140TY	610-054I3-001
3XSE736EA	180/140TY	007-635-077-03
3XSE746EA	180/140TY	007-636-077-03
3XSEV1016EA	140TY	610-05533-001
3XSEV1006EA	180/140TY	610-05583-001
3XSEV1026EA	180/140TY	069586D
3XSEV1066EA	140TY	610-055I3-001
3XSEV1036EA	140TY	610-055N3-001
3XSEV1046EA	140TY	610-055S3-001
3XSEV1506EA	180/140TY	610-05683-001
3XSEV1526EA	140TY	610-056D3-001
3XSEV1566EA	140TY	015-626-077-03
3XSEV1536EA	140TY	015-635-077-03
3XSEV1546EA	140TY	610-056S3-001
3XSEV2006EA	210/180TY	610-05783-001
3XSEV2026EA	210/180TY	610-057D3-001
3XSEV2066EA	140TY	020-626-077-03
3XSEV2036EA	140TY	610-057N3-001
3XSEV2046EA	140TY	610-057S3-001

NOTE: 1 Standard motor includes, 25 foot power and control cables, moisture & temperature sensors and carbon/ceramic/buna-n Inner & Outer shaft seals.

NOTE: 2 When ordering motor (item 17), Outer seal is supplied. Item 20 is for Outer seal replacement ONLY. When ordering outer seal, furnish Reliance motor serial number.

**Series: 3XSE-EA, 1.5 - 3.0HP, 1750RPM
3XSEV-EA, 2.0 - 7.5HP, 1750RPM**

PARTS LIST

ITEM	QTY	DESCRIPTION	PART NO.
1	8	Hex Hd Screw 3/8-16 x 1.75" Lg, Stainless	1-39-1
	8	Hex Hd Screw, 3XSEV 5-7.5HP 1/2-13 x 2.25" Lg, Stainless	1-73-1
2	1	Adapter Plate	4360
	1	Adapter Plate, 3XSEV 5-7.5HP	4361
3	1	Volute 3XSE	014-00003-101
		3XSEV	014-00003-103
		3XSEV 5-7.5HP	014-00003-104

ITEM #4 - IMPELLER, CAST IRON			
IMPELLER DIA.	3XSE - PART NO	3XSEV - PART NO	3XSEV-5-7.5HP - PART NO.
5.00	4366-A-101 - 1.5HP	4365-A-101 - 2HP	4365-B-101
5.12	4366-A-103	4365-A-103	4365-B-103
5.25	4366-A-105	4365-A-105	4365-B-105
5.37	4366-A-107	4365-A-107	4365-B-107
5.50	4366-A-109 - 2HP	4365-A-109 - 3HP	4365-B-109
6.62	4366-A-111	4365-A-111	4365-B-111
5.75	4366-A-113	4365-A-113	4365-B-113
5.87	4366-A-115	4365-A-115	4365-B-115
6.00	4366-A-117	4365-A-117	4365-B-117 - 5HP
6.12	4366-A-119	4365-A-119	4365-B-119
6.25	4366-A-121 - 3HP	4365-A-121	4365-B-121
6.37	4366-A-123	4365-A-123	4365-B-123
6.50	4366-A-125	4365-A-125	4365-B-125
6.62	N/A	4365-A-127	4365-B-127
6.75	N/A	4365-A-129	4365-B-129
6.87	N/A	4365-A-131	4365-B-131
7.00	N/A	4365-A-133	4365-B-133 - 7.5HP
7.12	N/A	4365-A-135	4365-B-135

5	6	Hex Hd Screw 5/16-18 x .75" Lg, Stainless	1-129-1
8	1	Socket Hd Screw, 3XSE 3/8-16 x 1.00" Lg, Stainless	11-62-1
	1	Socket Hd Screw, 3XSEV 3/8-16 x 1.25" Lg, Stainless	11-63-1
	1	Socket Hd Screw, 3XSEV - 5-7.5HP 1/2-13 x 1.50" Lg, Stainless	11-82-1
9	1	Impeller Washer	4367-01
	1	Impeller Washer, 3XSEV 5-7.5HP	4367-02
12	3Ft	Steel Chain, .250	625-01584
	4Ft	Steel Chain, .312, (5.0HP - 1Ph)	625-01582
13	3	Cold Shut, .312	625-00830
	3	Cold Shut, .375, (5.0HP - 1Ph)	625-00828
14	1	Warning Tag	625-03031
15	6	Lockwasher 5/16" Stainless	20-22-1
16	3	Leg	4321R
17	1	Motor	SEE TABLE 1
20	1	Outer Seal, (Supplied with Motor)	
21	1	Shaft Key, (Supplied with Motor)	

**Series: 3XSE-EA, 1.5 - 3.0HP, 1750RPM
3XSEV-EA, 2.0 - 7.5HP, 1750RPM**

PUMP MODEL	MOTOR FRAME/ FLANGE	TABLE 1 - MOTOR WITH VARIOUS CABLE LENGTHS							
		25FT	30FT	40FT	50FT	75FT	100FT	125FT	150FT
3XSE1504EA	180/140TY	610-05693-001							
3XSE1524EA	180/140TY	069586	069586XC	069586XE	069586XF	069586XH	069586XL	069586XN	069586XS
3XSE1564EA	180/140TY	069587D							
3XSE1534EA	180/140TY	069587	069587XC	069587XE	069587XF	069587XH	069587XL	069587XN	069587XS
3XSE1544EA	180/140TY	069588	069588XC	069588XE	069588XF	069588XH	069588XL	069588XN	069588XS
3XSE2004EA	180/140TY	610-05793-001							
3XSE2024EA	180/140TY	069589	069589XC	069589XE	069589XF	069589XH	069589XL	069589XN	069589XS
3XSE2064EA	180/140TY	069590VA							
3XSE2034EA	180/140TY	069590	069590XC	069590XE	069590XF	069590XH	069590XL	069590XN	069590XS
3XSE2044EA	180/140TY	069591	069591XC	069591XE	069591XF	069591XH	069591XL	069591XN	069591XS
3XSE3064EA	180/140TY	610-05893-001							
3XSE3024EA	180/140TY	093615	093615XC	093615XE	093615XF	093615XH	093615XL	093615XN	093615XS
3XSE3064EA	180/140TY	069551M							
3XSE3034EA	180/140TY	069551	069551XC	069551XE	069551XF	069551XH	069551XL	069551XN	069551XS
3XSE3044EA	180/140TY	069552	069552XC	069552XE	069552XF	069552XH	069552XL	069552XN	069552XS
3XSEV2004EA	140TY	610-05793-001							
3XSEV2024EA	180/140TY	069589	069589XC	069589XE	069589XF	069589XH	069589XL	069589XN	069589XS
3XSEV2064EA	140TY	069590VA							
3XSEV2034EA	140TY	069590	069590XC	069590XE	069590XF	069590XH	069590XL	069590XN	069590XS
3XSEV2044EA	140TY	069591	069591XC	069591XE	069591XF	069591XH	069591XL	069591XN	069591XS
3XSEV3004EA	180TY	610-05893-001							
3XSEV3024EA	180TY	093615	093615XC	093615XE	093615XF	093615XH	093615XL	093615XN	093615XS
3XSEV3064EA	140TY	069551M							
3XSEV3034EA	140TY	069551	069551XC	069551XE	069551XF	069551XH	069551XL	069551XN	069551XS
3XSEV3044EA	140TY	069552	069552XC	069552XE	069552XF	069552XH	069552XL	069552XN	069552XS
3XSEV5004EA	210/180TY	610-05993-001							
3XSEV5024EA	210/180TY	069560	069560XC	069560XE	069560XF	069560XH	069560XL	069560XN	069560XS
3XSEV5064EA	180TY	069554E							
3XSEV5034EA	180TY	069554	069554XC	069554XE	069554XF	069554XH	069554XL	069554XN	069554XS
3XSEV5044EA	180TY	069555	069555XC	069555XE	069555XF	069555XH	069555XL	069555XN	069555XS
3XSEV7564EA	180TY	069556H							
3XSEV7534EA	180TY	069556	069556XC	069556XE	069556XF	069556XH	069556XL	069556XN	069556XS
3XSEV7544EA	180TY	069557	069557XC	069557XE	069557XF	069557XH	069557XL	069557XN	069557XS

NOTE: 1 Standard motor includes, 25 foot power and control cables, moisture & temperature sensors and carbon/ceramic/buna-n Inner & Outer shaft seals.

NOTE: 2 When ordering motor (item 17), Outer seal is supplied. Item 20 is for Outer seal replacement ONLY. When ordering outer seal, furnish Reliance motor serial number.

IMPORTANT!
WARRANTY REGISTRATION

Your product is covered by the enclosed Warranty.
Complete the Warranty Registration Form and return to
Crane Pumps & Systems, Inc. Warranty Service Group

If you have a claim under the provision of the warranty, contact your local
Crane Pumps & Systems, Inc. Distributor.

RETURNED GOODS

**RETURN OF MERCHANDISE REQUIRES A "RETURNED GOODS AUTHORIZATION".
CONTACT YOUR LOCAL CRANE PUMPS & SYSTEMS, INC. DISTRIBUTOR.**



**Products Returned Must Be Cleaned, Sanitized,
Or Decontaminated As Necessary Prior To Shipment,
To Insure That Employees Will Not Be Exposed To Health
Hazards In Handling Said Material. All Applicable Laws
And Regulations Shall Apply.**

BARNES®

Limited Warranty

We warrant to our immediate customer and to the ultimate consumer that products of our manufacture will be free of defects in material and workmanship under normal use and service for the following time periods, when installed and maintained in accordance with our instructions.

Pump Products: One (1) year from date of installation or (24) twenty-four months from date of shipment, whichever occurs first. Cleaning Products: Twelve (12) months from date of installation or eighteen (18) months from date of shipment, whichever occurs first. As used herein, "the ultimate consumer" is defined as the purchaser who first uses the product after its initial installation or, in the case of product designed for non permanent installation, the first owner who used the product. It is the purchaser's or any sub-vendee's obligation to make known to the ultimate consumer the terms and conditions of this warranty. This warranty gives you specific legal rights, and there may also be other rights which vary from state to state. In the event the product is covered by the Federal Consumer Product Warranties Law (1) the duration of any implied warranties associated with the product by virtue of said law is limited to the same duration as stated herein, (2) this warranty is a LIMITED WARRANTY, and (3) no claims of any nature whatsoever shall be made against us, until the ultimate consumer, his successor, or assigns, notifies us in writing of the defect, and delivers the product and/or defective part(s) freight prepaid to our factory or nearest authorized service station. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply. **THE SOLE AND EXCLUSIVE REMEDY FOR BREACH OF ANY AND ALL WARRANTIES WITH RESPECT TO ANY PRODUCT SHALL BE TO REPLACE OR REPAIR AT OUR ELECTION, F.O.B. POINT OF MANUFACTURE OR AUTHORIZED REPAIR STATION, SUCH PRODUCTS AND/OR PARTS AS PROVEN DEFECTIVE. THERE SHALL BE NO FURTHER LIABILITY, WHETHER BASED ON WARRANTY, NEGLIGENCE OR OTHERWISE.** Unless expressly stated otherwise, guarantees in the nature of performance specifications furnished in addition to the foregoing material and workmanship warranties on a product manufactured by us, if any, are subject to laboratory tests corrected for field performance. Any additional guarantees, in the nature of performance specifications must be in writing and such writing must be signed by our authorized representative. Due to inaccuracies in field testing if a conflict arises between the results of field testing conducted by or for user, and laboratory tests corrected for field performance, the latter shall control. Components or accessories supplied by us but manufactured by others are warranted only to the extent of and by the terms and conditions of the original manufacturer's warranty. **RECOMMENDATIONS FOR SPECIAL APPLICATIONS OR THOSE RESULTING FROM SYSTEMS ANALYSES AND EVALUATIONS WE CONDUCT WILL BE BASED ON OUR BEST AVAILABLE EXPERIENCE AND PUBLISHED INDUSTRY INFORMATION. SUCH RECOMMENDATIONS DO NOT CONSTITUTE A WARRANTY OF SATISFACTORY PERFORMANCE AND NO SUCH WARRANTY IS GIVEN.**

This warranty shall not apply when damage is caused by (a) improper installation, (b) improper voltage (c) lightning (d) sand or other abrasive material (e) scale or corrosion build-up due to excessive chemical content. Any modification of the original equipment will also void the warranty. We will not be responsible for loss, damage or labor cost due to interruption of service caused by defective parts. Neither will we accept charges incurred by others without our prior written approval. This warranty is void if our inspection reveals the product was used in a manner inconsistent with normal industry practice and/or our specific recommendations. The purchaser is responsible for communication of all necessary information regarding the application and use of the product. **UNDER NO CIRCUMSTANCES WILL WE BE RESPONSIBLE FOR ANY OTHER DIRECT OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOST PROFITS, LOST INCOME, LABOR CHARGES, DELAYS IN PRODUCTION, IDLE PRODUCTION, WHICH DAMAGES ARE CAUSED BY ANY DEFECTS IN MATERIAL AND/OR WORKMANSHIP AND/OR DAMAGE OR DELAYS IN SHIPMENT. THIS WARRANTY IS EXPRESSLY IN LIEU OF ANY OTHER EXPRESS OR IMPLIED WARRANTY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

No rights extended under this warranty shall be assigned to any other person, whether by operation of law or otherwise, without our prior written approval.

CRANE[®]

A Crane Co. Company

PUMPS & SYSTEMS

420 Third Street
Piqua, Ohio 45356
Phone: (937) 778-8947
Fax: (937) 773-7157
www.cranepumps.com

83 West Drive, Bramton
Ontario, Canada L6T 2J6
Phone: (905) 457-6223
Fax: (905) 457-2650

START-UP REPORT FOR SUBMERSIBLE PUMPS

This form is designed to provide assurance that customer service and a quality product are the number one priority with Crane Pumps & Systems, Inc (CP&S). Please fill out the following questions as completely and accurate as possible. When complete, mail this form to:

In U.S.A Send To:
Crane Pumps & Systems, Inc
Attn: Warranty Service Group
420 Third Street
Piqua, Ohio 45356

In Canada Send To:
Crane Pumps & Systems, Inc.
Attn: Service Manager
83 West Drive, Brampton
Ontario, Canada L6T 2J6

REPORTS THAT ARE NOT RETURNED CAN DELAY OR VOID WARRANTY.

Pump Owner's Name: _____

Address: _____

Location of Installation _____

Person in Charge _____ Phone _____

Purchased From (Crane Pumps & Systems Representative/Distributor) _____

Pump Model _____ Serial No. _____

Part Number _____

Voltage _____ Phase _____ Hertz _____ Horespower _____

Rotation: Direction of impeller rotation (Use C/W for clockwise, CC/W for counter-clockwise) _____

Method used to check rotation (viewed from bottom) _____

Does impeller turn freely by hand: Yes _____ No _____

Condition of equipment Good _____ Fair _____ Poor _____

Condition of cable jacket Good _____ Fair _____ Poor _____

Resistance of cable jacket Good _____ Fair _____ Poor _____

Resistance of cable and pump motor (measured at pump control)

Red-Black _____ Ohms, Red-White _____ Ohms, White-Black _____ Ohms

Resistance of Ground Circuit between Control Panel and outside of pump _____ Ohms

MEG Ohms check of insulation:

Red to Ground _____ White to Ground _____ Black to Ground _____

Condition of equipment at Start-Up: Dry _____ Wet _____ Muddy _____

Was Equipment Stored? _____ Length of Storage _____

Describe station layout _____

Liquid being pumped _____

Debris in bottom of station? _____

Was debris removed in your presence? _____

Are guide rails exactly vertical? _____

Is BAF stationary installed level? _____

Liquid level controls: Model _____

Are level controls installed away from turbulence? _____

Operation Check:

Tip lowest float (Stop Float), All pumps should remain off.

Tip second float (and Stop Float), one pump comes On.

Tip third float (and Stop Float), both pumps on (alarm on simplex).

Tip fourth float (and Stop Float), high level alarm on (omit on simplex).

If not CP&S level controls, describe type of controls _____

Does liquid level ever drop below volute top? _____

CP&S control panel part no. and brand _____

Number of pumps operated by control panel _____

NOTE: At no time should holes be made in top of control panel, unless proper sealing devices are utilized.

Control panel manufactured by others _____

Company name _____

Model number _____

Short circuit protection _____ Type _____

Number and size of short circuit device(s) _____ Amp rating _____

Overload type _____ Size _____ Amp rating _____

Do protection devices comply with pump and motor Amp rating? _____

Are all connections tight? _____

Is the interior of the panel dry? _____

ELECTRICAL READINGS:

Single Phase:

Voltage supply at panel line connection, Pump Off, L1, L2 _____

Voltage supply at panel line connection, Pump On, L1, L2 _____

Amperage: Load connection, Pump On L1 _____ L2 _____

Three Phase:

Voltage supply at panel line connection, Pump Off, L1 - L2 _____ L2 - L3 _____ L3 - L1 _____

Voltage supply at panel line connection, Pump On, L1 - L2 _____ L2 - L3 _____ L3 - L1 _____

Amperage: Load connection, Pump On L1 _____ L2 _____ L3 _____

FINAL CHECK:

Is pump seated on discharge properly? _____ Check for leaks? _____

Does check valve(s) operate properly? _____

Flow, Does station appear to operate at proper rate? _____ Pump down time _____

Noise level: High _____ Medium _____ Low _____

Comments: _____

Equipment difficulties during start-up: _____

MANUALS:

Has operator received pump instructions and parts manual? _____

Has operator received electrical control panel diagram? _____

Has operator been briefed on Warranty? _____

Address of local CP&S Representative/Distributor: _____

I have received the above information (Name of Operator) _____

Name of Company _____

Date: _____

I Certify this report to be accurate (Name of Start-Up person) _____

Employed By: _____ Date: _____

Date and time of Start-Up _____

Present at Start-Up

() Engineer: _____ () Operator: _____

() Contactor: _____ () Other: _____

To be filled out by factory:

Start-Up form checked by: _____ Date warranty registration mailed: _____

IMPORTANT!
WARRANTY REGISTRATION

Your product is covered by the enclosed Warranty.
Complete the Warranty Registration Form and return to
Crane Pumps & Systems, Inc. Warranty Service Group

If you have a claim under the provision of the warranty, contact your local
Crane Pumps & Systems, Inc. Distributor.

FOLD HERE AND TAPE, DO NOT STAPLE

.....

**** IMPORTANT! ****

WARRANTY REGISTRATION

CUSTOMER'S NAME _____ **DATE INSTALLED** _____

ADDRESS _____

CITY _____ **STATE** _____ **ZIP** _____

PHONE # _____ **FAX #** _____

DEALER'S NAME _____

CITY _____ **STATE** _____ **ZIP** _____

MODEL NO. _____ **SERIAL NO.** _____

PART NO. _____ **BRAND** _____

FOLD HERE AND TAPE, DO NOT STAPLE

PLACE
STAMP
HERE

**CRANE PUMPS & SYSTEMS, INC.
WARRANTY SERVICE GROUP
420 THIRD STREET
PIQUA, OHIO
45356 - U.S.A.**