

35FR PLUNGER PUMP SERVICE MANUAL



SPLIT MANIFOLD PLUNGER PUMPS 35 FRAME [3507 and 3517] 35 FRAME [3510 and 3515]

CAUTION: CAT PUMPS are positive displacement pumps. Therefore, a properly designed pressure RELIEF OR SAFETY VALVE MUST BE INSTALLED in the discharge piping. Failure to install such a relief

mechanism could result in personal injury or damage to the pump or system. CAT PUMPS does not assume any liability or responsibility for the operation of a customer's high pressure system.

INSTALLATION AND START-UP INFORMATION

Optimum performance of the pump is dependent upon the entire fluid system and will be obtained only with the proper selection, installation of plumbing and operation of the pump and accessories.

SPECIFICATIONS: Maximum specifications refer to individual attributes. It is **not** implied that **all maximums** can be performed **simultaneously**. If more than one maximum is considered, check with your CAT PUMPS supplier to confirm the proper performance and pump selection.

LUBRICATION: Fill crankcase with special CAT PUMP oil per pump specifications [4.2 Qts. - 4.0 L]. **DO NOT RUN PUMP WITHOUT OIL IN CRANKCASE.** Change initial fill after 50 hours running period. Thereafter, change oil every **3 months or 500 hour intervals**. **Oiler adjustment** is vertical to start feed, dial to adjust flow rate. Additional lubrication may be required with increased hours of operation and temperature.

PUMP ROTATION: Pump was designed for forward rotation to allow optimum lubrication of the crosshead area. Reverse rotation is acceptable if the crankcase oil level is increased slightly above center dot to assure adequate lubrication.

PULLEY SELECTION: Select size of motor pulley required to deliver the desired volume from Horsepower Requirement and Pulley Selection Chart.

MOTOR SELECTION: The motor or engine driving the pump must be of adequate horsepower to maintain full RPM when the pump is under load. Select the electric motor from the Horsepower Requirement Chart according to required pump discharge volume, maximum **pressure at the pump** and drive losses of approximately 3-5%. Consult the manufacturer of gas or diesel engine for selection of the proper engine size.

Mount the pump on a rigid, horizontal surface in a manner to permit drainage of crankcase oil. An uneven mounting surface will cause extensive damage to the pump base. To minimize piping stress, **use appropriate flexible hose to inlet and discharge ports**. Use the correct belt; make sure pulleys are aligned. Excessive belt tension may be harmful to the bearings. Hand rotate pump before starting to be certain shaft and bearings are free moving.

LOCATION: If the pump is used in extremely dirty or humid conditions, it is recommended pump be enclosed. Do not store or operate in excessively high temperature areas or without proper ventilation.

INLET CONDITIONS: Refer to complete **Inlet Condition Check-List** in this manual before starting system. **DO NOT STARVE THE PUMP OR RUN DRY.**

C.A.T.: Installation of a C.A.T. (Captive Acceleration Tube) is recommended in applications with stressful inlet conditions such as high temperatures, booster pump feed, long inlet lines or quick closing valves.

DISCHARGE PLUMBING: OPEN ALL VALVES BEFORE STARTING SYSTEM to avoid deadhead overpressure condition and severe damage to the pump or system.

Install a **Pulsation Dampening** device mounted directly to the discharge line. Be certain the pulsation dampener (Prrrrr-o-lator) is properly precharged for the system pressure (see individual Prrrrr-o-lator data sheet).

A **reliable Pressure Gauge** should be installed near the discharge outlet of the high pressure manifold. This is extremely important for adjusting pressure regulating devices and also for proper sizing of the nozzle or restricting orifice. The pump is rated for a maximum pressure; this is the **pressure** which would be **read at the discharge manifold of the pump, NOT AT THE GUN OR NOZZLE.**

A Pressure Regulator or Unloader Valve must be installed to prevent over pressurizing the pump in the event the discharge or downstream plumbing becomes plugged or is turned off. Severe damage to the pump will result if this condition occurs without a relief valve in the line. **CAUTION: Failure to install such a safety valve will void the warranty on the pump. Discharge regulating devices should be at minimum pressure setting at start-up.** On systems over 2000 PSI SECONDARY PROTECTION is recommended by installing a pop-off valve, safety valve or rupture disc. **START SYSTEM WITH ALL VALVES OPEN OR IN THE LOW PRESSURE SETTING.**

Use PTFE liquid (sparingly) or tape to connect accessories or plumbing. Exercise caution not to wrap tape beyond the last thread to avoid tape from becoming lodged in the pump or accessories. This condition will cause a malfunction of the pump or system.

NOZZLES: A worn nozzle will result in loss of pressure. Do not adjust pressure regulating device to compensate. Replace nozzle and reset regulating device to system pressure.

PUMPED FLUIDS: Some fluids may require a **flush between operations or before storing**. For pumping fluids other than water, contact your CAT PUMPS supplier.

STORING: For extended storing or between use in cold climates, drain all pumped fluids from pump and **flush with antifreeze solution to prevent freezing and damage** to the pump. **DO NOT RUN PUMP WITH FROZEN FLUID.**

Products described hereon are covered by one or more of the following U.S. patents 3558244, 3652188, 3809508, 3920356, 3930756 and 5035580

World Headquarters

CAT PUMPS

1681 - 94th Lane N.E. Minneapolis, MN 55449-4324

Phone (612) 780-5440 — FAX (612) 780-2958

e-mail: sales@catpumps.com

www.catpumps.com

International Inquiries

FAX (612) 785-4443

e-mail: intlsales@catpumps.com



CAT PUMPS (U.K.) LTD.

1 Fleet Business Park, Sandy Lane, Church Crookham, Fleet

Hampshire GU13 0BF, England

Phone Fleet 44 1252-622031 — Fax 44 1252-626655

N.V. CAT PUMPS INTERNATIONAL S.A.

Heveldekens 6A, 2550 Kontich, Belgium

Phone 32-3-450.71.50 — Fax 32-3-450.71.51




e-mail: cpi@catpumps.be

CAT PUMPS DEUTSCHLAND GmbH

Buchwiese 2, D-65510 Idstein, Germany

Phone 49 6126-93030 — Fax 49 6126-930333

e-mail: catpumps@t-online.de



SERVICING THE VALVES


Disassembly

1. Using a standard M8 allen wrench, remove the six (6) M10 hex socket screws on each of the Valve Plugs and remove plugs. Inlet and Discharge Valves may be serviced at different schedules.
2. Remove the Coil Springs from the valve chambers.
3. With a standard pliers, grasp the Spring Retainer by the top tab and remove Valve Assembly. The flat Washer will rest on top of the retainer. **NOTE:** Normally the Valve Assembly will remain together. To separate the Valve Assembly, place a screwdriver into the side of the Spring Retainer and press on the back of the Valve until the Spring Retainer and Seat separate. If assembly separates, lift Spring and Valve from chamber by hand, using valve seat removal tool or the head of a 5/16" x 4" (M8x100) bolt. Insert under lip of the Valve Seat and lift out. This procedure will avoid damaging the surface of the Valve Seat.

Reassembly

NOTE: For certain applications apply liquid gasket to the o-ring crevices and seal surfaces. See Tech Bulletin 53 for model identification.

1. Examine the O-Rings and Back-up-Rings on the Seat and replace if cut or worn.
2. Examine the surface of the Valve and Seat for pitting, grooves or wear and replace if necessary.
3. If servicing from individual parts, place the Seat with O-Ring and Back-up-Ring on work surface with o-ring side down. Place Valve onto Seat with the raised side up. Place the Spring over the raised backside of the Valve. Securely snap the Spring Retainer into the Seat. The Valve Assemblies come preassembled in the valve kit. **NOTE:** Inlet and discharge valve parts are interchangeable. **Two valve kits** are needed for complete valve change.
4. Press Valve Assembly squarely into chamber.
5. Place Washer and Coil Spring on top of Retainer.
6. Examine the O-Ring and Back-up-Ring on Valve Plug and replace if cut or worn. Press Valve Plug into valve chamber. Exercise caution not to cut O-Ring or Back-up-Ring.
7. Reinstall six (6) M10 hex socket screws on each Valve Plug and hand tighten using torque sequence. Then torque all screws per chart.



REMOVING DISCHARGE MANIFOLD

1. Remove the eight (8) M12 hex socket head screws.
2. Tap the back side of the Discharge Manifold with a soft mallet and gradually work from pump.
3. Remove the O-Rings from lower Inlet Manifold chamber.

REMOVING THE INLET MANIFOLD

1. Remove the four (4) M14 hex socket head screws.
2. Rotate Crankshaft to separate Inlet Manifold from the Crankcase.
3. Tap the rear of the Inlet Manifold with a soft mallet. Support from underside and gradually work from the pump. Exercise caution and keep manifold aligned with Plungers to avoid damaging them as the manifold is removed.

SERVICING THE PACKINGS


Disassembly of the V-Packings


The V-Packing Cylinder may remain in either the Inlet or Discharge Manifold and generally may be removed by hand or with a reverse pliers.

1. Place the **crankcase side** of the Inlet Manifold **down** on the work surface.
2. Remove the V-Packing Cylinder by inserting screwdrivers into the exposed groove on opposite sides and pry out of the chamber.
3. With valve seat removal tool or reverse pliers remove the V-Packing Spacer from the center of the V-Packing Cylinder. The V-Packing Spacers may remain in the V-Packing Cylinder or Discharge Manifold. If in the Discharge Manifold, insert screwdrivers from opposite sides into groove on Spacer and pry out.
4. Next remove the Male Adapter, V-Packings and Female Adapter from the V-Packing Cylinder.

Reassembly of V-Packings

1. Examine the exterior O-Rings on the V-Packing Cylinder and replace if cut or worn.
2. Inspect I.D. of V-Packing Cylinder for pitting or grooves and replace as needed.
3. Insert the new Female Adapter into the V-Packing Cylinder with the **"v" side up**. (See Tech Bulletin 53).





4. Assemble the three (3) V-Packings (Model 3507), two (2) V-Packings (Model 3517) and insert into the V-Packing Cylinder with "**v**" side up.
5. Next insert Male Adapter into V-Packing Cylinder with **notches up**.
6. Examine O-Ring and Back-up-Ring on V-Packing Spacer and replace if cut or worn.
7. Insert **smaller diameter** end of V-Packing Spacer into V-Packing Cylinder.
8. Invert the Inlet Manifold with **crankcase side down**. Press the V-Packing Cylinder containing V-Packing Spacer and V-Packings into manifold chambers until completely seated.

Disassembly of Lo-Pressure Seal

1. Place the Inlet Manifold on blocks with **crankcase side down**.
2. Use a screwdriver or the head of the 5/16"x4" (M8 x 100) bolt to drive out Lo-Pressure Seal and Inlet Adapter.
3. Separate stainless steel Washer from Inlet Adapter.
4. Then place Inlet Adapter on V-Packing cylinder and drive out Lo-Pressure Seal using a socket sized to fit.

Reassembly Lo-Pressure Seal

NOTE: For certain applications apply liquid gasket to the o-ring crevices and seal surfaces. See Tech Bulletin 53 for model identification.

1. With **crankcase side of Inlet Manifold facing up**, insert Washer into manifold chamber.
2. Examine O-Ring on Inlet Adapter and replace if cut or worn.
3. Place Inlet Adapter with **o-ring side down** and insert new pre-greased Lo-Pressure Seal into the Inlet Adapter with **garter spring facing up**. Press squarely into position (See Tech Bulletin 53).
4. Next insert Inlet Adapter and Lo-Pressure Seal with **garter spring facing down** and press squarely into manifold chamber.

SERVICING THE PLUNGERS

Disassembly



1. Remove the Seal Retainers from the ceramic plungers.
2. Remove the used Wick.
3. Loosen Plunger Retainer 3 to 4 turns. Push Ceramic Plunger towards Crankcase until Plunger Retainer pops out. If resistant, slip M14 deep socket over Plunger Retainer and gently tap end to free Ceramic Plunger.

4. Unthread and remove Plunger Retainer, Gasket, O-Ring and Back-up-Ring.
5. Remove Ceramic Plunger from Plunger Rod.
6. Barrier Slinger and Keyhole Washer will remain on the Plunger Rod. Remove and examine for wear.

Reassembly

NOTE: For certain applications apply liquid gasket to the o-ring crevices and seal surfaces. See Tech Bulletin 53 for model identification.

1. With these plunger items removed, examine the Crankcase Oil Seals for wear or deterioration and replace as needed.
2. Replace Barrier Slinger and Keyhole Washer on Plunger Rod.
3. Carefully examine each Plunger for scoring or cracks and replace if worn. NOTE: Ceramic Plunger can only be installed one direction (**larger I.D. out**).
4. Examine O-Ring and Back-up-Ring on Plunger Retainer and replace if cut or worn. Lubricate O-Ring for ease of installation and to avoid damaging O-Rings. NOTE: First install O-Ring, then Back-up-Ring, then Gasket. Apply Loctite 242 to Plunger Retainer threaded end and thread onto Plunger Rod. Torque per specifications.
5. Slip Seal Retainers over Plungers. Insert smaller diameter first. NOTE: Line up Wicks with the oil holes in the Crankcase and tabs in the Oil Pan.
6. Rotate shaft and line up two outside Plungers.
7. Carefully lubricate Plungers and slip Inlet Manifold onto Plungers and press into Crankcase. Keep manifold aligned to avoid damaging Plungers. Press completely into Crankcase.
8. Reinstall four (4) M14 hex socket head screws and torque per chart.
9. Examine inlet port O-Rings at bottom of manifold and replace if cut or worn.
10. Carefully slip Discharge Manifold over V-Packing Spacers. (See Tech Bulletin 53).
11. Hand tighten the eight (8) M12 hex socket screws and torque per chart in this sequence.
Torque in order diagonally the center four (4) screws then the outer four (4) screws all hand tight then repeat series to specs.



INLET CONDITION CHECK-LIST

Review Before Start-Up

SERVICING THE CRANKCASE SECTION

1. While manifold, plungers and seal retainers are removed, examine crankcase seals for wear.
2. Check oil level and for evidence of water in oil.
3. Rotate crankshaft by hand to feel for smooth bearing movement.
4. Examine crankshaft oil seal externally for drying, cracking or leaking.
5. Consult factory or your local distributor if crankcase service is evidenced.

Inadequate inlet conditions can cause serious malfunctions in the best designed pump. Surprisingly, the simplest of things can cause the most severe problems or go unnoticed to the unfamiliar or untrained eye. **REVIEW THIS CHECK-LIST BEFORE OPERATION OF ANY SYSTEM.** Remember, no two systems are alike, so there can be no **ONE** best way to set-up a system. All factors must be carefully considered.

PREVENTATIVE MAINTENANCE CHECK-LIST

Check	Daily	Weekly	50 hrs.	500 hrs.*	1500 hrs.**
Clean Filters	x				
Oil Level/Quality	x				
Oil Leaks	x				
Water Leaks	x				
Belts, Pulley		x			
Plumbing		x			
Initial Oil Change			x		
Oil Change				x	
Seal Change					x
Valve Change					x
Accessories					x

*If other than CAT PUMPS special multi-viscosity ISO68 oil is used, change cycle should be every 300 hours.
 **Each system's maintenance cycle will be exclusive. If system performance decreases, check immediately. If no wear at 1500 hours, check again at 2000 hours and each 500 hours until wear is observed.
 ***Remember to service the regulator/unloader at each seal servicing and check all system accessories and connections before resuming operation.

INLET SUPPLY should be adequate to accommodate the maximum flow being delivered by the pump.

- Open inlet shut-off valve and turn on water supply to avoid cavitating pump. **DO NOT RUN PUMP DRY.**
- Avoid closed loop systems especially with high temperature, ultra-high pressure or large volumes. Conditions vary with regulating/unloader valve.
- Low vapor pressure fluids, such as solvents, require a booster pump and C.A.T. (Captive Acceleration Tube) to maintain adequate inlet supply.
- Higher viscosity fluids require a positive head and a C.A.T. (Captive Acceleration Tube) to assure adequate inlet supply.
- Higher temperature fluids tend to vaporize and require positive heads and C.A.T. (Captive Acceleration Tube) to assure adequate inlet supply.
- When using an inlet supply reservoir, size it to provide adequate fluid to accommodate the maximum output of the pump, generally a minimum of 6 to 10 times the GPM (however, a combination of system factors can change this requirement); provide adequate baffling in the tank to eliminate air bubbles and turbulence; install diffusers on all return lines to the tank.

INLET LINE SIZE should be adequate to avoid starving the pump.

- Line size must be a minimum of one size larger than the pump inlet fitting. Avoid thick walled fittings, tees, 90 degree elbows or valves in the inlet line of the pump to reduce the risk of flow restriction and cavitation.
- The line **MUST** be a FLEXIBLE hose, NOT a rigid pipe, and reinforced on SUCTION systems to avoid collapsing.
- The simpler the inlet plumbing the less the potential for problems. Keep the length to a minimum, the number of elbows and joints to a minimum (ideally no elbows) and the inlet accessories to a minimum.
- Use pipe sealant to assure air-tight, positive sealing pipe joints.

INLET PRESSURE should fall within the specifications of the pump.

- Acceleration loss of fluids may be increased by high RPM, high temperatures, low vapor pressures or high viscosity and may require pressurized inlet and C.A.T. (Captive Acceleration Tube) to maintain adequate inlet supply. **DO NOT USE C.A.T (Captive Acceleration Tube) WITH SUCTION INLET.**
- Optimum pump performance is obtained with +20 PSI (1.4 BAR) inlet pressure and a C.A.T. for certain applications. With adequate inlet plumbing, most pumps will perform with flooded suction. Maximum inlet pressure is 70 PSI (5 BAR).
- After prolonged storage, pump should be purged of air to facilitate priming. Disconnect any discharge port and allow fluid to pass through pump.

INLET ACCESSORIES are designed to protect against overpressurization, control inlet flow, contamination or temperature and provide ease of servicing.

- A shut-off valve is recommended to facilitate maintenance.
- Installation of a C.A.T. (Captive Acceleration Tube) is essential in applications with stressful conditions such as high temperatures, booster pump feed or long inlet lines. **Do not use C.A.T. with negative inlet pressure.**
- A stand pipe can be used in some applications to help maintain a positive head in the inlet line.
- Inspect and clean inlet filters on a regular schedule.
- A pressure gauge is recommended to monitor the inlet pressure and should be mounted AS CLOSE TO THE PUMP INLET as possible. **Short term, intermittent cavitation will not register on a standard gauge.**
- All accessories should be sized to avoid restricting the inlet flow.
- All accessories should be compatible with the solution being pumped to prevent premature failure or malfunction.

BY-PASS TO INLET Care should be exercised when deciding the method of by-pass from control valves.

- It is recommended the by-pass be directed to a baffled reservoir tank, with at least one baffle between the by-pass line and the inlet line to the pump.
- Although not recommended, by-pass fluid may be returned to the inlet line of the pump if the system is properly designed to protect your pump. When using this method a PRESSURE REDUCING VALVE should be installed on the inlet line (**BETWEEN THE BY-PASS CONNECTION AND THE INLET TO THE PUMP**) to avoid excessive pressure to the inlet of the pump when a flow sensitive regulating device is used. It is also recommended that a THERMO VALVE be used in the by-pass line to monitor the temperature build-up in the by-pass loop to avoid premature seal failure.
- A low-pressure, flexible cloth braid (not metal braid) hose should be used from the by-pass connection to the inlet of the pump.
- Caution should be exercised not to undersize the by-pass hose diameter and length. Refer to Technical Bulletin 64 for additional information on the size and length of the by-pass line
- Check the pressure in the by-pass line to avoid overpressurizing the inlet.
- The by-pass line should be connected to the pump inlet line at a gentle angle of 45° or less and no closer than 10 times the pump inlet port diameter e.g. 1-1/2" port size = 15" distance from pump inlet port.

TORQUE CHART

Pump Item Pump Model	Thread	Tool Size [Part No.]	Torque		
			in. lbs.	ft. lbs.	Nm
Plunger Retainer Models 3507, 3510	M7	M14 Hex [25053]	90	7.2	10
Plunger Retainer Models 3515, 3517	M10	M21 Hex	220	18.1	25
Inlet Manifold Screws All Models	M14	M12 Allen [33048]	480	39.8	55
Discharge Manifold Screws All Models	M12	M10 Allen [33047]	350	28.9	40
Valve Plug Screws All Models	M10	M8 Allen [33046]	220	18.1	25
Crankcase Cover/ Bearing Cover Screws All Models	M8	M13 Hex [25324]	115	9.4	13
Connecting Rod Screws All Models	M10	M17 Hex [25083]	395	32.5	45
Bubble Oil Gauge All Models	M28	Oil Gauge Tool [44050]	45	3.6	5
Mounting Bolts All Models	M14	M22	600	47.4	68

TECHNICAL BULLETIN REFERENCE CHART

No.	Subject	Models
002	Inlet Temperature vs. Inlet Pressure	All Models
003	5FR - 68FR Drive Packages	5FR - 68FR Plunger Models
024	Lubrication of Lo-Pressure Seals	All Models
035	Servicing Crankcase Section - Plunger Pumps	5FR, 7FR, 15FR
036	Cylinder and Plunger Reference Chart	All Models
041	Crankcase Changes	35FR
043	Plunger Pump LPS and HPS Servicing	All Plunger Models
052	Plunger Rod and Stud Change - CR Pumps	3FR, 5FR, 15FR, 35FR, 60FR
053	Liquid Gasket	5FR, 7FR, 15FR, 35FR, 60FR
064	By-Pass Hose Length	All Unloaders/Regulators
068	Discharge Valve Spacer and O-Ring Change	3507
069	35 Frame Forged Extended Manifolds	3520, 3521, 3527, 3535, 3531, 3537, 3507, 3517
074	Piston and Plunger Pump Torque Chart	All Models
077	Oil Drain Kit	All Models

HOSE FRICTION LOSS

Water* Flow Gal/Min	PRESSURE DROP IN PSI PER 100 FT OF HOSE WITH TYPICAL WATER FLOW RATES Hose Inside Diameters, Inches						
	1/4	5/16	3/8	1/2	5/8	3/4	1"
0.5	16	5	2				
1	54	20	7	2			
2	180	60	25	6	2		
3	380	120	50	13	4	2	
4		220	90	24	7	3	
5		320	130	34	10	4	
6			220	52	16	7	1
8			300	80	25	10	2
10			450	120	38	14	3
15			900	250	80	30	7
20			1600	400	121	50	12
25				650	200	76	19
30					250	96	24
40					410	162	42
50					600	235	62
60						370	93

*At a fixed flow rate with a given size hose, the pressure drop across a given hose length will be directly proportional. A 50 ft. hose will exhibit one-half the pressure drop of a 100 ft. hose. Above values shown are valid at all pressure levels.

WATER LINE PRESSURE LOSS PRESSURE DROP IN PSI PER 100 FEET

Water GPM	Steel Pipe—Nominal Dia.						Brass Pipe—Nominal Dia.						Copper Tubing O.D. Type L								
	1/4	3/8	1/2	3/4	1	1 1/4	1 1/2	1/4	3/8	1/2	3/4	1	1 1/4	1 1/2	1/4	3/8	1/2	5/8	3/4	7/8	
1	8.5	1.9					6.0	1.6							120	13	2.9	1.0			
2	30	7.0	2.1				20	5.6	1.8						400	45	10	3.4	1.3		
3	60	14	4.5	1.1			40	11	3.6						94	20	6.7	2.6			
5	150	36	12	2.8			100	28	9.0	2.2					230	50	17	6.1	3.0		
8	330	86	28	6.7	1.9		220	62	21	5.2	1.6				500	120	40	15	6.5		
10	520	130	43	10	3.0		320	90	30	7.8	2.4				180	56	22	10			
15	270	90	21	6.2	1.6		190	62	16	5.0	1.5				120	44	20				
25	670	240	56	16	4.2	2.0	470	150	40	12	3.8	1.7			330	110	50				
40				66	17	8.0				39	11	5.0			550	200	88				
60					37	17						23	11								
80						52	29						40	19							
100						210	107	48					61	28							


RESISTANCE OF VALVES AND FITTINGS

Nominal Pipe Size Inches	Inside Diameter Inches	Equivalent Length of Standard Pipe in Feet							
		Gate Valve	Globe Valve	Angle Valve	45° Elbow	90° Elbow	180° Close Ret	Tee Thru Run	Tee Thru Branch
1/2	0.622	0.41	18.5	9.3	0.78	1.67	3.71	0.93	3.33
3/4	0.824	0.54	24.5	12.3	1.03	2.21	4.90	1.23	4.41
1	1.049	0.69	31.2	15.6	1.31	2.81	6.25	1.56	5.62
1 1/4	1.380	0.90	41.0	20.5	1.73	3.70	8.22	2.06	7.40
1 1/2	1.610	1.05	48.0	24.0	2.15	4.31	9.59	2.40	8.63
2	2.067	1.35	61.5	30.8	2.59	5.55	12.30	3.08	11.60
2 1/2	2.469	1.62	73.5	36.8	3.09	6.61	14.70	3.68	13.20
3	3.068	2.01	91.5	45.8	3.84	8.23	18.20	4.57	16.40
4	4.026	2.64	120.0	60.0	5.03	10.80	23.90	6.00	21.60

Arriving at a total line pressure loss, consideration should then be given to pressure loss created by valves, fittings and elevation of lines.

If a sufficient number of valves and fittings are incorporated in the system to materially affect the total line loss, add to the total line length, the equivalent length of line of each valve or fitting.

TYPICAL RESERVOIR TANK RECOMMENDED 6 TO 10 TIMES SYSTEM CAPACITY



Handy Formulas to Help You

Q. How can I find the RPM needed to get specific GPM (Gallons Per Minute) I want?

A. $\text{Desired RPM} = \text{Desired GPM} \times \frac{\text{Rated RPM}}{\text{Rated GPM}}$

Q. I have to run my pump at a certain RPM. How do I figure the GPM I'll get?

A. $\text{Desired GPM} = \text{Desired RPM} \times \frac{\text{Rated GPM}}{\text{Rated RPM}}$

Q. Is there a simple way to find the approximate horsepower I'll need to run the pump?

A. $\text{Electric Brake Horsepower Required} = \frac{\text{GPM} \times \text{PSI}}{1460} \left(\frac{\text{Standard 85\% Mech. Efficiency}}{\text{Mech. Efficiency}} \right)$

Q. What size motor pulley should I use?

A. $\text{Pump Pulley (Outer Diameter)} \times \frac{\text{Pump RPM}}{\text{Motor/Engine RPM}}$ (Consult Engine Mfr.)

Q. How do I calculate the torque for my hydraulic drive system?

A. $\text{Torque (ft. lbs.)} = 3.6 \left(\frac{\text{GPM} \times \text{PSI}}{\text{RPM}} \right)$

Avoid Cavitation Damage



One or several of the conditions shown in the chart below may contribute to cavitation in a system resulting in premature wear, system downtime and unnecessary operating costs.

CONDITION	SOLUTION
Inadequate inlet line size	<ul style="list-style-type: none"> • Increase line size to the inlet port or one size larger
Water hammering / fluid acceleration / deacceleration	<ul style="list-style-type: none"> • Install C.A.T. Tube • Move pump closer to fluid supply
Rigid Inlet Plumbing	<ul style="list-style-type: none"> • Use flexible wire reinforced hose to absorb pulsation and pressure spikes
Excessive Elbows in Inlet Plumbing	<ul style="list-style-type: none"> • Keep elbows to a minimum and less than 90°
Excessive Fluid Temperature	<ul style="list-style-type: none"> • Use Thermo Valve in bypass line • Do not exceed pump temperature specifications • Substitute closed loop with baffled holding tank • Adequately size tank for frequent or high volume bypass • Pressure feed high temperature fluids • Properly ventilate cabinets and rooms
Air Leaks in Plumbing	<ul style="list-style-type: none"> • Check all connections • Use Teflon tape
Agitation in Supply Tank	<ul style="list-style-type: none"> • Size tank according to pump output — Minimum 6-10 times system GPM • Baffle tank to purge air from fluid and separate inlet from discharge
High Viscosity Fluids	<ul style="list-style-type: none"> • Verify viscosity against pump specifications before operation • Elevate fluid temperature enough to reduce viscosity • Lower RPM of pump • Pressure feed pump • Increase inlet line size
Clogged Filters	<ul style="list-style-type: none"> • Perform regular maintenance or use clean filters to monitor build up • Use adequate mesh size for fluid and pump specifications

DIAGNOSIS AND MAINTENANCE

PROBLEM	PROBABLE CAUSE	SOLUTION
<ul style="list-style-type: none"> Pulsation 	<ul style="list-style-type: none"> Faulty Pulsation Dampener Material lodged in discharge valve 	<ul style="list-style-type: none"> Check precharge. If low, recharge it or install a new one. Clean and replace damaged valve.
<ul style="list-style-type: none"> Low Pressure 	<ul style="list-style-type: none"> Worn nozzle Belt slippage Air leak in inlet plumbing Pressure gauge inoperative or not registering accurately Relief valve stuck, partially plugged or improperly adjusted; valve seat worn Inlet suction strainer clogged or improper size Worn Packing. Abrasives in pumped fluid or severe cavitation. Inadequate water supply Fouled or dirty inlet or discharge valves Worn inlet or discharge valves Leaky discharge hose 	<ul style="list-style-type: none"> Replace nozzle of proper size. Tighten or replace. Use correct belt type and length. Disassemble, reseal, and reassemble. Check with new gauge; replace worn or damaged gauge. Clean and adjust relief valve; check for worn or dirty valve seats. Repair with Valve Kit. Clean. Use adequate size. Check more frequently. Install proper filter. Check flow available to pump. Clean inlet and discharge valve assemblies. Replace worn valves, valve seats and/or discharge hose. Check fitting or replace damaged hose.
<ul style="list-style-type: none"> Pump runs extremely rough, pressure low 	<ul style="list-style-type: none"> Restricted inlet or air entering the inlet plumbing Inlet restrictions and/or air leaks. Stuck inlet or discharge valve Leaking V-Packings Cavitation 	<ul style="list-style-type: none"> Proper size inlet plumbing; check for air tight seal. Clean out foreign material, replace worn valves. Repair with Seal Kit. Check water temperature and inlet conditions.
<ul style="list-style-type: none"> Water leakage from under the manifold 	<ul style="list-style-type: none"> Worn V-Packings and Lo-Pressure Seals Worn male and female adapter Excessive wear. Operation beyond normal service cycle 	<ul style="list-style-type: none"> Repair with Seal Kit. Install new male and female adapter. Initiate more frequent service cycle.
<ul style="list-style-type: none"> Oil leak between crankcase and pumping section 	<ul style="list-style-type: none"> Worn crankcase piston rod seals 	<ul style="list-style-type: none"> Replace crankcase piston rod seals.
<ul style="list-style-type: none"> Oil leaking in the area of crankshaft 	<ul style="list-style-type: none"> Worn crankshaft seal or improperly installed oil seal retainer O-ring Bad bearing 	<ul style="list-style-type: none"> Remove oil seal retainer and replace damaged O-ring and/or seals. Replace bearing.
<ul style="list-style-type: none"> Excessive play in the end of the crankshaft pulley 	<ul style="list-style-type: none"> Worn main bearing from excessive tension on drive belt 	<ul style="list-style-type: none"> Replace bearing. Properly tension belt. Use correct type and length.
<ul style="list-style-type: none"> Water in crankcase 	<ul style="list-style-type: none"> May be caused by humid air condensing into water inside the crankcase Worn and leaking V-Packing. Operating beyond normal service cycle. 	<ul style="list-style-type: none"> Change oil every 3 months or 500 hour intervals using special CAT PUMP Premium Grade Oil, PN 06100 (Case) 6107 (Bottle), (other approved oil every month or 200 hours). Repair with seal kit. Initiate more frequent service cycle.
<ul style="list-style-type: none"> Oil leaking from under-side of crankcase 	<ul style="list-style-type: none"> Worn crankcase seals 	<ul style="list-style-type: none"> Replace seals.
<ul style="list-style-type: none"> Oil leakage from drain plug 	<ul style="list-style-type: none"> Loose drain plug or worn drain plug O-ring 	<ul style="list-style-type: none"> Tighten drain plug or replace O-ring.
<ul style="list-style-type: none"> Loud knocking noise in pump 	<ul style="list-style-type: none"> Pulley loose on crankshaft Broken or worn bearing Stressful inlet conditions 	<ul style="list-style-type: none"> Check key and tighten set screw. Replace bearing. Install C.A.T. and/or booster pump.
<ul style="list-style-type: none"> Frequent or premature failure of the packing 	<ul style="list-style-type: none"> Scored plungers Over pressure to inlet manifold Abrasive material in the fluid being pumped Excessive pressure and/or temperature of fluid being pumped Running pump dry; cavitation 	<ul style="list-style-type: none"> Replace plungers. Reduce inlet pressure per instructions. Install proper filtration on pump inlet plumbing. Check pressure and inlet fluid temperature. Be sure they are within specified range. DO NOT RUN PUMP WITHOUT WATER.
<ul style="list-style-type: none"> Strong surging at the inlet and low pressure on the discharge side 	<ul style="list-style-type: none"> Foreign particles in the inlet or discharge valve or worn inlet and/or discharge valves Stressful inlet conditions 	<ul style="list-style-type: none"> Check for smooth lap surfaces on inlet and discharge valve seats. Discharge valve seats and inlet valve seats may be lapped on a very fine oil stone. Install C.A.T. and/or booster pump.