


# DEMING®

## INSTALLATION, OPERATION & MAINTENANCE MANUAL Vertical Process Pumps



Series: 5460

**IMPORTANT!**

***Read all instructions in this manual before operating pump.  
As a result of Crane Pumps & Systems, Inc., constant product improvement program,  
product changes may occur. As such Crane Pumps & Systems reserves the right to  
change product without prior written notification.***

**CRANE**<sup>®</sup>

A Crane Co. Company

### PUMPS & SYSTEMS

420 Third Street  
Piqua, Ohio 45356  
Phone: (937) 778-8947  
Fax: (937) 773-7157  
www.cranepumps.com

83 West Drive, Brampton  
Ontario, Canada L6T 2J6  
Phone: (905) 457-6223  
Fax: (905) 457-2650

Form No. 120024-Rev. C

# CONTENTS

SAFETY FIRST .....	3
A. GENERAL INFORMATION.....	4
Receiving	
Storage	
Service Centers	
B. BEFORE YOU BEGIN .....	4
C. INSTALLATION .....	4
D. DIRECTION OF ROTATION.....	4
E. OPERATION.....	4
F. PUMP ADJUSTMENT .....	5
G. IMPELLER ADJUSTMENT.....	5
H. DISCHARGE PIPE.....	5
I. LUBRICATION.....	5
J. GENERAL MAINTENANCE & REPAIRS .....	5
K. FOR INSPECTION OR REPAIR OF LIQUID END.....	5 - 6
L. TO INSPECT BALL BEARINGS & SEAL OR SHAFT .....	6
M. TO REASSEMBLE BALL BEARINGS AND SEALS.....	6 - 7
N. ASSEMBLY OF LIQUID END.....	7
O. CHAIR BRACKET MOUNTING.....	7 - 8
P. LOCATING TROUBLE .....	8
CROSS-SECTION & PARTS LIST .....	9
WARRANTY & RETURNED GOODS .....	11

# SAFETY FIRST!

Please Read This Before Installing Or Operating Pump. This information is provided for **SAFETY** and to **PREVENT EQUIPMENT PROBLEMS**. To help recognize this information, observe the following symbols:



**IMPORTANT!** Warns about hazards that can result in personal injury or indicates factors concerned with assembly, installation, operation, or maintenance which could result in damage to the machine or equipment if ignored.

**CAUTION!** Warns about hazards that **can or will cause minor** personal injury or property damage if ignored. Used with symbols below.

**WARNING!** Warns about hazards that can or will cause serious personal injury, death, or major property damage if ignored. Used with symbols below.



*Hazardous fluids can cause fire or explosions, burns or death could result.*



*Extremely hot - Severe burns can occur on contact.*



*Biohazard can cause serious personal injury.*



*Hazardous fluids can cause hazardous pressure, eruptions or explosions could cause personal injury or property damage.*




*Rotating machinery Amputation or severe laceration can result.*



*Hazardous voltage can shock, burn or cause death.*

Only qualified personnel should install, operate and repair pump. Any wiring of pumps should be performed by a qualified electrician.



**WARNING!** To reduce risk of electrical shock, pumps and control panels must be properly grounded in accordance with the National Electric Code (NEC) or the Canadian Electrical Code (CEC) and all applicable state, province, local codes and ordinances. Improper grounding voids warranty.



**WARNING!** To reduce risk of electrical shock, always disconnect the pump from the power source before handling or servicing. Lock out power and tag.



**WARNING!** Operation against a closed discharge valve will cause premature bearing and seal failure on any pump, and on end suction and self priming pump the heat build may cause the generation of steam with resulting dangerous pressures. It is recommended that a high case temperature switch or pressure relief valve be installed on the pump body.



**CAUTION!** Never operate a pump with a plug-in type power cord without a ground fault circuit interrupter.



**CAUTION!** Pumps build up heat and pressure during operation-allow time for pumps to cool before handling or servicing.



**WARNING!** Do not pump hazardous materials (flammable, caustic, etc.) unless the pump is specifically designed and designated to handle them.



**CAUTION!** Do not block or restrict discharge hose, as discharge hose may whip under pressure.



**WARNING!** Do not wear loose clothing that may become entangled in moving parts.



**WARNING!** Keep clear of suction and discharge openings. **DO NOT** insert fingers in pump with power connected.



Make sure lifting handles are securely fastened each time before lifting. **DO NOT** operate pump without safety devices in place. Always replace safety devices that have been removed during service or repair. Secure the pump in its operating position so it can not tip over, fall or slide.



**DO NOT** exceed manufacturers recommendation for maximum performance, as this could cause the motor to overheat.



**DO NOT** remove cord and strain relief. **DO NOT** connect conduit to pump.



**WARNING!** Cable should be protected at all times to avoid punctures, cut, bruises and abrasions. Inspect frequently. Never handle connected power cords with wet hands.



**WARNING!** To reduce risk of electrical shock, all wiring and junction connections should be made per the NEC or CEC and applicable state or province and local codes. Requirements may vary depending on usage and location.



**WARNING!** Submersible Pumps are not approved for use in swimming pools, recreational water installations decorative fountains or any installation where human contact with the pumped fluid is common.



**WARNING!** Products returned must be cleaned, sanitized, or decontaminated as necessary prior to shipment, to insure that employees will not be exposed to health hazards in handling said material. All Applicable Laws And Regulations Shall Apply.



Bronze/brass and bronze/brass fitted pumps may contain lead levels higher than considered safe for potable water systems. Lead is known to cause cancer and birth defects or other reproductive harm. Various government agencies have determined that leaded copper alloys should not be used in potable water applications. For non-leaded copper alloy materials of construction, please contact factory.



Crane Pumps & Systems, Inc. is not responsible for losses, injury, or death resulting from a failure to observe these safety precautions, misuse or abuse of pumps or equipment.

## A - GENERAL INFORMATION

### TO THE PURCHASER:

Congratulations! You are the owner of one of the finest pumps on the market today. These pumps are products engineered and manufactured of high quality components. With years of pump building experience along with a continuing quality assurance program combine to produce a pump which will stand up to the toughest applications.

Check local codes and requirements before installation. Servicing should be performed by knowledgeable pump service contractors or authorized service stations.

### RECEIVING:

Upon receiving the pump, it should be inspected for damage or shortages. If damage has occurred, file a claim immediately with the company that delivered the pump. If the manual is removed from the crating, do not lose or misplace.

### STORAGE:

**Short Term** - Pumps are manufactured for efficient performance following long inoperative periods in storage. For best results, pumps can be retained in storage, as factory assembled, in a dry atmosphere with constant temperatures for up to six (6) months.

**Long Term** - Any length of time exceeding six (6) months, but not more than twenty four (24) months. The units should be stored in a temperature controlled area, a roofed over walled enclosure that provides protection from the elements (rain, snow, wind blown dust, etc.), and whose temperature can be maintained between +40 deg. F and +120 deg. F. Pump should be stored in its original shipping container and before initial start up, rotate impeller by hand to assure seal and impeller rotate freely.

### SERVICE CENTERS:

For the location of the nearest Deming Service Center, check your Deming representative or Crane Pumps & Systems Service Department in Piqua, Ohio, telephone (937) 778-8947 or Crane Pumps & Systems Canada, Inc., Bramton, Ontario, (905) 457-6223.

## B - BEFORE YOU BEGIN

These pumps are assembled, carefully adjusted and lubricated at the factory before shipment.

When motors are shipped unmounted or supplied by the user, the motor and flexible shaft coupling must be mounted on the pump at time of installation.

If pump is furnished with chair bracket for mounting horizontal type motor, the motor shaft must be carefully aligned with pump shaft before installing flexible shaft coupling. See "Chair Bracket Mounting".

## C - INSTALLATION

1. Carefully lower the assembled pumping unit into the tank or pit. The base plate (23) must rest evenly at all points and must be level before it is bolted to the foundation. Shim and grout to level the base plate. Install foundation bolts.
2. If motor and shaft coupling were shipped unmounted:
  - a. Install coupling (42) on the motor shaft and pump shaft according to coupling manufacturer's recommendations.
  - b. Lift the motor over the driver pedestal (81) and carefully lower the motor until it rests on the pedestal. Insert and tighten cap screws (219). Complete coupling assembly and tighten coupling setscrews.
3. Rotate pump shaft by hand several times to be sure that it rotates freely. If shaft binds, refer to the section on "Pump Adjustment".
4. A check valve and gate valve should be installed in the discharge piping near the pump discharge to prevent damage to the pump due to reverse flow upon the pump shut-down.

Connect discharge piping to the pump discharge. The weight of the pipe and valves must be supported so that the weight does not rest on pump discharge connection, as this may cause misalignment. Do not pull pipe into position with flange bolts.

5. Rotate shaft again by hand several times to be sure that it rotates freely.

## D - DIRECTION OF ROTATION

Connect power leads to motor terminals according to wiring diagram on the motor and to the motor control or starter. Remove motor cap screws (219) and disengage the shaft coupling. Jog control to test for proper pump rotation. Standard pump rotate clockwise when looking down on top of the motor, see rotation arrow on the pump. If rotation is incorrect, on 3 phase current interchange the 2 main power leads at the starter and test for rotation again. When proper rotation is established mark the power leads to the proper starter terminals and reassemble the shaft coupling and replace motor cap screws.

## E - OPERATION

Start the pump and check again for proper rotation. Pump should operate smoothly and without vibration. If pump vibrates, impeller adjustment may be incorrect or there may be distortion of the pump base plate (23) or the discharge piping. Refer to section on "Pump Adjustment".

## F - PUMP ADJUSTMENT

If after making the installation as above and the pump shaft does not rotate freely or if there is vibration in the pumping unit, the following adjustments are recommended. **LOCK ENTRANCE DISCONNECT SWITCH IN THE OFF POSITION** and separate the coupling halves before proceeding.

## G - IMPELLER ADJUSTMENT

An outstanding feature of this pump is the ability to adjust the impeller clearance to compensate for eventual wear or to modify the design performance of the pump.

The normal clearance between the impeller vanes and suction cover (9) or the casing (1) at the suction inlet is .012 to .015 inches which provides optimum operating performance. To adjust the impeller clearance, proceed as follows:

1. Disengage flexible shaft coupling.
2. Unscrew the 3 adjusting lock nuts (204) until they are against the heads of the jackscrews (286) then unscrew the jackscrews several turns.
3. Tighten the 3 cap screws (213) evenly by alternating the cap screws until the shaft can no longer be turned by hand at the coupling. This will lower the rotating assembly, seating the impeller (2) against the suction cover or casing.
4. Loosen the cap screws (213) ½ turn. Carefully tighten the 3 jackscrews (286) by alternating the jackscrews approximately 1 - 1½ hex to obtain the desired .015 inches clearance. Retighten the cap screws (213) until snug and then tighten the adjusting lock nuts (204) to lock adjustment. Make sure that the shaft turns freely by hand before starting the pump.
5. Reassemble coupling and place pump in operation.

## H - DISCHARGE PIPE

Improper alignment of the discharge pipe (161) may cause the shaft to bind. Loosen the top pipe lock nut (294) 2 to 3 turns and test for shaft rotation. If shaft is free, gradually tighten the top pipe lock nut checking shaft rotation as the nut is tightened.

If the shaft still binds, lift the pump from the tank or pit and loosen the bottom pipe lock nut. Continue to tighten the top pipe lock nut and the binding should be relieved. Tighten the bottom pipe lock nut when maximum shaft freedom has been accomplished and make sure that the top pipe lock nut is tight.

An accurate check of the impeller and pump alignment can be established by the use of a watt meter to measure the minimum power requirement of the motor.

## I - LUBRICATION

The pump bearings (18) and (16) and the lip seals (47) and (49) were properly lubricated at the factory before shipment. Periods of subsequent lubrication will depend on local conditions, hours of operation, speed, temperature, etc.

It is recommended that the bearings and seals be periodically inspected and lubricated. As a guide we would recommend the following frequency.

Pump Service	Ambient Temperature	Lubrication Interval
8 hours per day	high	6 to 8 weeks
	low	12 weeks
24 hours per day	high	3 to 4 weeks
	low	6 to 8 weeks

A lithium base grease of medium consistency with corrosion resistant inhibiting properties must be used for the ball bearings and the lip seals. Shell Alvania #2 or equal is recommended.

Motor bearings should be lubricated in accord with motor manufacturer's recommendations.

## J - GENERAL MAINTENANCE & REPAIRS

Care should be exercised in keeping all parts of the pump clean when out of the pump. Special precautions must be taken to keep ball bearings and lip seals dirt-free at all times.

Any part which is excessively worn or deteriorated and all gaskets should be replaced with new parts before reassembling the pump.


When ordering repairs, refer to the illustration for correct item names and to the pump nameplate on which is stamped the pump model number, size and serial number which must be available when ordering repairs.

## K - FOR INSPECTION OR REPAIR OF LIQUID END

1. Close the gate valve in the discharge line and **LOCK THE ENTRANCE DISCONNECT SWITCH IN THE OFF POSITION.**
2. Remove power leads from the motor. Disconnect the discharge pipe at the pump base plate.
3. Disengage the flexible shaft coupling, per manufacturer's instructions. Remove motor cap screws (219) then remove motor from the motor pedestal (81). Remove foundation bolts in the base plate (23), and lift pump and base plate from pit to the floor or other suitable support.



4. a. If the pump is furnished with threaded discharge fittings, unscrew the pipe coupling or flange (295) from the top end of the discharge pipe then remove the top pipe nut (294) and unscrew the lower pipe nut to the end of the threads. Unscrew the discharge pipe (161) from the discharge elbow (105).
- b. If the pump is furnished with combination elbow (105), remove the cap screws and nuts (267) and (268) at the pump discharge flange.



5. Liquid end disassembly
  - a. Remove cap screws (215), then place a block of wood against the finished flange or back of the suction cover (9) and tap the block lightly with a hammer to loosen the suction cover. Remove the suction cover and the gasket (73).
  - b. Bend and remove the cotter pin (269) and the castellated impeller nut (24). Hold shaft with a wrench at the coupling (42) and unscrew the impeller nut (24) by turning counter clockwise, also remove the impeller washer (270).
  - c. To remove impeller (2) from the shaft (6) it will be necessary to make 3 special jackscrews depending upon the size of the liquid end as follows:
    - 1.) If the discharge outlet of the casing (1) is threaded 1", 1½" or 2½" and the impeller diameter is 6" or less, the required jackscrews are 3/8" x 16NC, 1¾" long.
    - 2.) For all other sizes of liquid ends the required jackscrews are 1/2" x 13NC, 3" long.
 Thread the jackscrews into the 3 tapped holes in the impeller shroud and tighten alternating jackscrews, until the impeller is forced from the shaft. Lift impeller key (32) from its seat.
  - d. The casing (1) and throttle housing (99) may be removed from the column pipe (101) after removing cap screws (212).

- e. Inspect the throttle bushing (252) for excessive wear and replace by unscrewing the cap screw (218) and pressing the bushing from the housing. Press new bushing into the throttle housing (99), aligning the slot with the cap screw (218) then tighten cap screw until firm. Slide deflector (40) from the shaft.

## L - TO INSPECT BALL BEARINGS & SEALS OR SHAFT

1. Remove Liquid end assembly.
2. Remove coupling (42) and key (46) from shaft (6).
3. Remove cap screws (221) and nuts (261) and lift driver pedestal (81) from frame (19).
4. Remove cap screw (213). Unscrew the 3 lock nuts (204) until against the head of the jackscrew (286) then remove jackscrews. Slide bearing cover (37) with seal (49) off the top end of the shaft (6). Inspect the seal and replace if worn.
5. Bend tape on bearing lock washer (69) then unscrew and remove the bearing lock nut (22) and bearing lock washer (69).
6. Replace the jackscrews (286) in the bearing housing flange and tighten the jackscrews to raise the bearing housing (33) and ball bearing (18) from the top of the frame (19). A pry bar may be required to assist in removing the bearing housing. Carefully press the ball bearing from the bearing housing.
7. Carefully withdraw the pump shaft and ball bearing (16) upward through the frame (19). Remove the bearing (16) from the shaft.
8. Inspect the bearing cover seal (47) and if worn replace with new seal. Bearing cover (35) and seal may be removed from the frame using a piece of pipe or tubing inserted through the top of the frame to force the bearing cover from the frame.

## M - TO REASSEMBLE BALL BEARINGS AND SEALS

1. Slide bearing (16) onto the shaft. Position the bearing so that the inner bearing race is against the shaft shoulder. **CAUTION:** Apply force only to the inner bearing race.
2. If the bearing cover (35) and the seal (47) were removed from the frame, apply sufficient grease to fill the space below the ball bearing (16). Press bearing cover with seal into the frame from the impeller end until the bearing cover is flushed with the frame. Be sure that seal (47) is installed with the spring side of the seal toward the impeller.

3. Insert shaft with bearing, impeller end first, into the top of the frame (19) being careful not to damage the seal (47).
4. Place bearing housing (33) in a vice with the flange resting on vice jaws. Apply light oil to interior of housing then press bearing (18) into the bearing housing making sure that the bearing is fully seated in the bearing housing. **CAUTION: Apply force to the outer ring of the bearing only.** Place the assembly over the end of the pump shaft and press into position so that the inner race of the bearing is against the shaft shoulder. **CAUTION: Apply force to the inner ring of the bearing only.**
5. Place lock washer (69) over the bearing and thread the bearing lock nut (22) onto the shaft and tighten securely. Bend tabs of lock washer into slots in the bearing lock nut.
6. If frame (19) was removed from the support plate (23), mount the frame on the base plate replacing cap screw and nuts (221) and (258)
7. Slide deflector (40) onto the shaft.

## N - ASSEMBLY OF LIQUID END

1. Place throttle housing (99) with throttle bushing over impeller end of shaft. Align bolt holes and position against column pipe (101).
2. Position gasket (241) on throttle housing (99) then place casing (1) against the flange of the throttle housing aligning the holes and with the discharge outlet in the proper position. Replace cap screws (212).
3. Insert impeller key (32) into shaft keyway and place impeller (2) on shaft with keyway over impeller key. Place wooden block over impeller vanes and tap lightly on the wood block to seat the impeller on the shaft. Back up coupling end of shaft to prevent bearing damage.
4. Replace impeller washer (270) onto the shaft then the castellated nut (24). Tighten the nut and place new cotter pin (269) through nut and shaft. **CAUTION: Do Not use impeller nut to draw the impeller onto the shaft. The nut is a locking device only.** Recommended torque for tightening the impeller nut is as follows:
  - 1/2" - 45 Ft. lbs.
  - 5/8" - 90 Ft. lbs.
  - 3/4" - 170 Ft. lbs.
5. Place gasket (73) on suction cover (9). Position cover against the casing (1) and replace and tighten cap screws (215).

## O - CHAIR BRACKET MOUNTING

(See page 8)

The foot mounted horizontal type motor and flexible shaft coupling are shipped unmounted and must be mounted on the pump prior to installation of the pump.

Mount the pump half coupling on the pump shaft (6) and the motor half coupling on the motor shaft according to manufacturer's recommendations.

Place the pump in a horizontal position on a bench or suitable support. Place motor, shaft toward the pump, on the chair bracket with motor feet positioned on the motor mounting screws (2).

Insert motor anchor cap screws (5) thru holes in motor feet and into the motor mounting screws. Tighten sufficiently to hold motor in position.

Adjust motor mounting screws until motor shaft and coupling is aligned with the pump shaft, both angular and paralleled alignment.

Angular alignment check is made by inserting taper gauge or feelers between coupling faces at 90° intervals around the coupling. The coupling faces should be the same distance apart. Adjust motor mounting screws to achieve alignment.


Paralleled alignment check is made by placing a straight edge across both coupling rims at 90° intervals around the coupling. Straight edge should rest evenly on coupling halves at each point. Correction can be made by adjusting motor mounting screws. When properly aligned, tighten motor anchor cap screws (5) and lock nuts (3).

Place the assemble pump in a vertical position on the tank or pit and connect discharge pipe to pump discharge. **NOTE: Pipe and fittings must be properly supported so their weight does not rest on pump.** Recheck angular and paralleled alignment and correct as necessary. Turn pump shaft by hand several times to be sure that it rotates freely.

Connect power leads to motor according to motor wiring diagram, jog starter, testing for proper pump rotation; normally clockwise (right hand) when looking down on top of motor.

Place pump in operation. If there is vibration in the unit, recheck alignment at the shaft coupling and refer to "Pump Adjustment".

## Chair Bracket Mounting




1	Motor Support
2	Motor Mounting Screw
3	Lock Nut
4	Motor Foot
5	Motor Anchor Cap Screw

### P - LOCATING TROUBLE

1. No water delivered
  - a. Wrong direction of rotation
  - b. Impeller or pipes plugged
  - c. Discharge head too high
  - d. No water in pit
  - e. Pump suction too close to bottom of pit
2. Not enough water delivered
  - a. Discharge head higher than expected
  - b. Impeller or pipes partly plugged
  - c. Improper impeller adjustment
  - d. Low water level in pit
  - e. Mechanical defects
    1. Impeller worn or damaged
    2. Casing worn
  - f. Wrong direction of rotation
3. Not enough pressure
  - a. Air in water
  - b. Mechanical defects
  - c. Impeller diameter too small
  - d. Wrong direction of rotation
  - e. Impeller not properly adjusted
  - f. Discharge head (line friction) lower than expected
4. Pump takes too much power
  - a. Speed too high for required head and capacity
  - b. Head lower than rating; pumps too much water
  - c. Liquid either viscous or heavier than water or both
  - d. Mechanical defects
    1. Shaft bent
    2. Impeller binds in casing
  - e. Strain on pump caused by piping misalignment
  - f. Impeller not adjusted properly





ITEM No.	DESCRIPTION
001	Casing
002	Impeller
006	Shaft
009	Suction Cover
*016	Ball Bearing (Inboard)
*018	Ball Bearing (Outboard)
019	Frame
022	Lock Nut (Bearing)
023	Base Plate
*024	Impeller Nut
032	Impeller Key
033	Bearing Housing (Outboard)
035	Bearing Cover (Inboard)
037	Bearing Cover (Outboard)
040	Deflector
042	Coupling
046	Coupling Key
*047	Bearing Cover Seal
*049	Bearing Cover Seal
069	Bearing Lock Washer
*073	Gasket
081	Drive Pedestal
099	Throttle Housing
101	Column
105	Discharge Elbow
161	Discharge Pipe
204	Adjusting Lock Nut
212	Cap Screw
213	Cap Screw
215	Cap Screw
218	Cap Screw
219	Cap Screw
221	Cap Screw
228	Motor
*241	Gasket
242	Grease Fitting
252	Throttle Bushing
258	Hex Nut
260	Cap Screw
261	Hex Nut
265	Cap Screw
267	Cap Screw
268	Cap Screw
*269	Cotter Pin
270	Impeller Washer
286	Jackscrew
294	Pipe Nut
295	Discharge Flange
332	Cap Screw (Not Shown)
335	Lube Pipe Assembly
*336	Gasket

(\*) Recommended Spare Parts

BARNES®



burks®

WEINMAN®

DEMING®

PROSSER®

## *Limited 24 Month Warranty*

Crane Pumps & Systems warrants that products of our manufacture will be free of defects in material and workmanship under normal use and service for twenty-four (24) months after manufacture date, when installed and maintained in accordance with our instructions. This warranty gives you specific legal rights, and there may also be other rights which vary from state to state. In the event the product is covered by the Federal Consumer Product Warranties Law (1) the duration of any implied warranties associated with the product by virtue of said law is limited to the same duration as stated herein, (2) this warranty is a LIMITED WARRANTY, and (3) no claims of any nature whatsoever shall be made against us, until the ultimate consumer, his successor, or assigns, notifies us in writing of the defect, and delivers the product and/or defective part(s) freight prepaid to our factory or nearest authorized service station. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply. **THE SOLE AND EXCLUSIVE REMEDY FOR BREACH OF ANY AND ALL WARRANTIES WITH RESPECT TO ANY PRODUCT SHALL BE TO REPLACE OR REPAIR AT OUR ELECTION, F.O.B. POINT OF MANUFACTURE OR AUTHORIZED REPAIR STATION, SUCH PRODUCTS AND/OR PARTS AS PROVEN DEFECTIVE. THERE SHALL BE NO FURTHER LIABILITY, WHETHER BASED ON WARRANTY, NEGLIGENCE OR OTHERWISE.** Unless expressly stated otherwise, guarantees in the nature of performance specifications furnished in addition to the foregoing material and workmanship warranties on a product manufactured by us, if any, are subject to laboratory tests corrected for field performance. Any additional guarantees, in the nature of performance specifications must be in writing and such writing must be signed by our authorized representative. Due to inaccuracies in field testing if a conflict arises between the results of field testing conducted by or for user, and laboratory tests corrected for field performance, the latter shall control. **RECOMMENDATIONS FOR SPECIAL APPLICATIONS OR THOSE RESULTING FROM SYSTEMS ANALYSES AND EVALUATIONS WE CONDUCT WILL BE BASED ON OUR BEST AVAILABLE EXPERIENCE AND PUBLISHED INDUSTRY INFORMATION. SUCH RECOMMENDATIONS DO NOT CONSTITUTE A WARRANTY OF SATISFACTORY PERFORMANCE AND NO SUCH WARRANTY IS GIVEN.**

This warranty shall not apply when damage is caused by (a) improper installation, (b) improper voltage (c) lightning (d) excessive sand or other abrasive material (e) scale or corrosion build-up due to excessive chemical content. Any modification of the original equipment will also void the warranty. We will not be responsible for loss, damage or labor cost due to interruption of service caused by defective parts. Neither will we accept charges incurred by others without our prior written approval.

This warranty is void if our inspection reveals the product was used in a manner inconsistent with normal industry practice and/or our specific recommendations. The purchaser is responsible for communication of all necessary information regarding the application and use of the product. **UNDER NO CIRCUMSTANCES WILL WE BE RESPONSIBLE FOR ANY OTHER DIRECT OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO TRAVEL EXPENSES, RENTED EQUIPMENT, OUTSIDE CONTRACTOR FEES, UNAUTHORIZED REPAIR SHOP EXPENSES, LOST PROFITS, LOST INCOME, LABOR CHARGES, DELAYS IN PRODUCTION, IDLE PRODUCTION, WHICH DAMAGES ARE CAUSED BY ANY DEFECTS IN MATERIAL AND/OR WORKMANSHIP AND/OR DAMAGE OR DELAYS IN SHIPMENT. THIS WARRANTY IS EXPRESSLY IN LIEU OF ANY OTHER EXPRESS OR IMPLIED WARRANTY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

No rights extended under this warranty shall be assigned to any other person, whether by operation of law or otherwise, without our prior written approval.

**CRANE**<sup>®</sup>

**PUMPS & SYSTEMS**

A Crane Co. Company

420 Third Street  
Piqua, Ohio 45356  
Phone: (937) 778-8947  
Fax: (937) 773-7157  
www.cranepumps.com

83 West Drive, Brampton  
Ontario, Canada L6T 2J6  
Phone: (905) 457-6223  
Fax: (905) 457-2650

**IMPORTANT!  
WARRANTY REGISTRATION**

Your product is covered by the enclosed Warranty.  
To complete the Warranty Registration Form go to:

<http://www.cranepumps.com/ProductRegistration/>

If you have a claim under the provision of the warranty, contact your local  
Crane Pumps & Systems, Inc. Distributor.

**RETURNED GOODS**

**RETURN OF MERCHANDISE REQUIRES A "RETURNED GOODS AUTHORIZATION".  
CONTACT YOUR LOCAL CRANE PUMPS & SYSTEMS, INC. DISTRIBUTOR.**



**Products Returned Must Be Cleaned, Sanitized,  
Or Decontaminated As Necessary Prior To Shipment,  
To Insure That Employees Will Not Be Exposed To Health  
Hazards In Handling Said Material. All Applicable Laws  
And Regulations Shall Apply.**

