


Large Sump or Drainage Pumps

Item No.	Name Of Part
1	Casing
2	Impeller
6A	Top Shaft
6	Bottom Shaft
9	Suction Cover
* 18	Ball Bearing
19	Frame
23	Base Plate
* 24	Impeller Nut
32	Impeller Key
33	Bearing Housing
* 39	Bearing Bushing
* 39A	Top Bearing Bushing
42	Coupling Half - Pump
44	Coupling Half - Driver
46	Coupling Key
48	Coupling Bushing
66	Shaft Adjusting Nut
70	Shaft Coupling
* 73	Gasket
101	Column
101A	Top Column Pipe
105	Discharge Elbow
161	Discharge Fitting
* 169	Seal - Lower
* 169A	Seal - Top
170	Bearing Adapter
199	Top Closure
202	Snap Ring
216	Pipe Plug
219	Cap Screw
226	Cap Screw (Not Shown)
241	Gasket
242	Grease Fitting
244	Brg. Adapter Key
246	Stud
247	Hex Nut
* 250	Frame Gasket
* 254	Pipe Nut Gasket
256	Hex Nut
257	Choker Ring
258	Hex Nut
260	Cap Screw
265	Cap Screw
267	Cap Screw
268	Hex Nut
270	Impeller Washer
277	Cap Screw
285	Cap Screw
288	Hex Nut
294	Pipe Nut
295	Discharge Flange
307	Bearing Retainer
316	Strainer
332	Cap Screw
335	Lube Pipe Assembly
* 336	Gasket
341	Hex Nut
342	Set Screw
350	Stud
351	Hex Nut



* Recommended spare parts



WARNING:

CANCER AND REPRODUCTIVE HARM -
WWW.P65WARNINGS.CA.GOV

SECTION 40-L
PAGE 6
DATE 10/18



A Crane Co. Company

PUMPS & SYSTEMS

USA: (937) 778-8947 • Canada: (905) 457-6223 • International: (937) 615-3598