



## REPAIR PARTS LIST

Key No.	Part Description	Qty.	BW85P	BW8512	EBW85-I
1	Screw, Cover	4	670-656	670-656	670-656
2	Cover Plate	1	230-298	230-298	230-298
3	O-Ring	1	546-023	546-023	546-023
4A	Outer Wearplate	1	721-122	721-122	721-122
4B	Inner Wearplate	1	721-122	721-122	721-122
5	Impeller	1	416-011	416-011	416-011
6	Cam Ring	1	134-007	134-007	134-007
7	Seal, U-Cup	1	16FA019-4	16FA019-4	16FA019-4
8	Washer	1	854-341	854-341	854-341
9	Housing Body	1	404-114-B	404-114-B	404-114-B
10	Screw	2	670-657	670-657	670-657
11	Water Slinger	1	RP0001616	RP0001616	RP0001616
12	Motor	1	*	*	*
13	Cord Set	1	992-695	992-695	992-684
14A	Fuse Holder	1	U17-1148	U17-1148	U17-1148
14B	Fuse	1	344-001	344-001	344-001
15	Pud-L-Scoop®	1	992-653	—	—
•	Accessory Package**	1	—	—	992-734

• Not illustrated.

\* If the motor fails, replace the pump.

\*\* Includes two hose couplings and two rubber washers.