



## Repair Parts

Key No.	Part Description	No. Used	FP4105 FP410515H	FP4107
1	Capacitor	1	171P5620	171P5430
2	Screw 3.5 x 12.7	11	121P2060	121P2060
3	Wiring Box and Cover	1	102P2870	102P2870
4	Wiring Box Cover Gasket	1	111P1350	111P1350
5	Pressure Switch	1	U217-1202	U217-1202
6	90° Hose Barb	2	U111-212T	U111-212T
7	Connector, 1/2" NSPM	1	J43-13C	J43-13C
•	Connector Lock Ring	1	U36-112ZP	U36-112ZP
8	Wiring Box Base Gasket	1	111P1340	111P1340
9	Seal Plate and Motor	1	†	†
10	Seal Plate Insert	1	101P1290	101P1290
11	O-Ring	1	111P0700	111P0700
12	Shaft Seal, Complete	1	ZBR00010	ZBR00010
13	Impeller	1	731S5700	731S2220
14	Diffuser/Nozzle/Venturi	1	101P3440	101P3440
15	O-Ring	1	111P0480	111P0480
16	Volute	1	731P1000	731P1000
17	Pressure Switch Tube	1	U37-669P	U37-669P
18	Motor Foot (FP4105, FP4107 only)	1	101P1400	101P1380
19	Fan	1	102P2010	102P0570
20	Motor End Cover	1	201P0150	201P0160
21	Flexible Pipe with Fitting (Tank to Pump, FP410515H Only)	1	ZA004870	ZA004870

† Not Available Separately. If needed, replace pump.