

Key No.	Part Description	Qty.	Key No.	Part Description	Qty.	Key No.	Part Description	Qty.
1	Motor/Seal Plate Assembly	1	8	Diffuser	1	15	Pump Body	1
1A	Motor Flange Screw	4	9	Diffuser Plate	1	15A	Pressure Regulator	1
2	Seal Plate O-Ring	1	10	Diffuser Plate O-Ring	1	16	Ejector Gasket	1
3	Pressure switch	1	11	Diffuser Plate Washer	3	17	Ejector Body	1
4	Shaft Seal	1	12	Diffuser Plate Screw	3	18	Washer	2
5	Impeller	1	13	Venturi	1	19	Ejector Capscrew	2
6	1/4" NPT x 1/4" Barb Elbow	2	14	Nozzle	1			
7	Hose	1						

**Pump Model and Horsepower**


Part Description	Shallow Well Pumps		
	FP4155 1/2 HP	FP4157 3/4 HP	FP4150 1 HP
Seal and O-Ring Kit	RPK-35	RPK-35	RPK-35
Overhaul Kit	RPK-205SW	RPK-207SW	RPK-210SW
Ejector Kit	-	-	-
Pump Body Assembly	R176-73	R176-73	R176-73
Pressure Switch (30-50)	TC2151	TC2151	TC2151
Pressure Switch Tubing	FPASFK	FPASFK	FPASFK
Pressure Regulator	-	-	-

**Kits Include:**

- Seal and O-Ring Kit
- Overhaul Kit (Shallow well)
- Overhaul Kit (Deep well)
- Ejector Kit (Deep well)
- Pump Body Assembly (313)
- Pump Body Assembly (312)
- Pressure Switch
- Pressure Switch Tubing Kit

*Kits Include:*

- Key Nos 2, 4, 10, 16
- Key Nos 1A, 2, 4, 5, 8, 9, 10, 11(3), 12(3), 13, 14
- Key Nos 1A, 2, 4, 5, 8, 9, 10, 11, 12
- Key Nos 6(2), 7, 13(5), 14(2), 16, 17, 18(2), 19(2)
- Key Nos 2, 6, 10, 15, 16, 1/4" NPT Plug(2), 1/2" NPT Plug
- Key Nos 2, 6, 13, 14, 15, 1/4" NPT Plug(2), 1/2" NPT Plug
- Key No 3
- Key Nos. 6(3), 7



Key No.	Part Description	Qty.	FP420515H	FP415515H
1A	Pressure Regulator	1	FPAPR	-
1B	Discharge Cross	1	-	U78-961P
1C	Reducer Bushing 1/2" NPT x 1/8" NPT	1	-	U78-107PT
1D	Pipe Plug 1" NPT	1	-	U78-1008P
•	Pipe Plug 1/8" NPT	1	-	WC78-41T
2	Pressure Gauge	1	TC2104	TC2104
3	3/4" NPT x 1" Hose Barb 90° Elbow	1	U78-770P	-
4	1" Hose Clamp	2	U19-55SS	U19-55SS
5	1" Hose	1	U74-37R	U74-37H
6	3/4" NPT x 1" Hose Barb Adapter	1	24206A004	24206A004
7	3/4" NPT x 3/4" NPT x 3/4" NPT Street Tee	1	05002A001	05002A001
8	5/16"-18 Flanged Nuts	6	U36-202BT	U36-202BT
9	Tank Flange	1	U31-442P	U31-442P
•	Tank Bladder	1	U20-7	U20-7
10	Tank Body	1	*	*
11	Air Valve with Cap	1	U212-160	U212-160

\* If tank body fails, replace entire tank (Part Number RT6H).

• Not illustrated.