



Pos. 3 und 18* nur bei Ausführung aus PP
 Pos. 4, 17 und 28 nur bei Ausführung aus PTFE

Pos. 3 and 18* only for model in PP
 Pos. 4, 17 and 28 only for model in PTFE

Rep. 3 et 18* seulement pour modèle en PP
 Rep. 4, 17 et 28 seulement pour modèle en PTFE

Pos. 3 en 18* alleen bij uitvoering in PP
 Pos. 4, 17 en 28 alleen bij uitvoering in PTFE



Pos. No.	Qty. per unit	Description	Part No.	Part No.
			RFM 40 PP	RFM 40 PTFE
		Version according to exploded view No. D40 80 000 – 05/2007 version as from Serial No. RFM00800		
1	10	Hexagonal nut	907 01 002	907 01 002
2	10	Spring washer	910 05 002	910 05 002
3	10	Washer	908 10 011	-
4	2	Support plate for pump housing	-	D40 70 063
5	16	Insert for pump housing	D25 70 016	D25 70 016
6	2	Pump housing	D40 70 009	D40 70 043
7	2	Diaphragm (NBR) <i>optional</i>	D40 70 035	D40 70 035
		Diaphragm (PTFE/EPDM) <i>optional</i>	D40 70 036	D40 70 036
		Diaphragm (EPDM) <i>optional</i>	D40 70 037	D40 70 037
		Diaphragm (FKM)	D40 70 038	D40 70 038
8	1	Bearing kit with o-rings	D40 70 200	D40 70 200
9	5	Tension rod	D40 70 031	D40 70 032
10	1	Selector shaft	D40 70 019	D40 70 019
11	2	Silencer	947 15 008	947 15 008
12	3	Plug G 1/2 A	947 05 047	947 05 047
13	4	Ball (NBR) <i>optional</i>	D40 70 001	D40 70 001
		Ball (PTFE) <i>optional</i>	D40 70 003	D40 70 003
		Ball (EPDM) <i>optional</i>	D40 70 004	D40 70 004
		Ball (FKM)	D40 70 002	D40 70 002
14	4	O-ring Ø64x4 (NBR) <i>optional</i>	925 93 025	925 93 025
		O-ring Ø64x4 (FFKM) <i>optional</i>	925 95 125	925 95 125
		O-ring Ø64x4 (EPDM) <i>optional</i>	925 95 118	925 95 118
		O-ring Ø64x4 (FKM)	925 95 117	925 95 117
15	4	Ball cage, rod-shaped	D40 70 086	D40 70 186
17	2	Support plate for manifold, discharge side	-	D40 70 064
18	16	Washer	908 08 011	-
	4	Washer	-	908 08 011
19	16	Spring washer	909 95 003	909 95 003
20	12	Hexagonal screw	900 91 023	900 91 023

Attention: Please always give full description, part no. and quantity of parts required.

This list consists of 3 pages

FLUX-GERÄTE GMBH D-75433 Maulbronn

Rights reserved to make alterations and/or modifications



**Spare Parts List Air-operated Diaphragm Pump
RFM 40 PP / RFM 40 PTFE**

Page : 3
Edition : 05/2007

Pos. No.	Qty. per unit	Description	Part No.	Part No.
			RFM 40 PP	RFM 40 PTFE
		Version according to exploded view No. D40 80 000 – 05/2007 version as from Serial No. RFM00800		
21	1	Air valve part complete with item 12 and 23	D40 70 134	D40 70 134
22	1	5/2-way control valve	D40 70 101	D40 70 101
23	2	Plug G 3/8 A	947 05 043	947 05 043
24	1	Manifold, suction or discharge side	D40 70 006	D40 70 040
25	2	Pedestal	D40 70 017	D40 70 066
28	2	Suppor plate for manifold, suction side	-	D40 70 065
29	4	Hexagonal screw	900 91 024	900 91 024
30	4	Guide sleeve	D40 70 082	D40 70 182
31	10	Hexagonal cap	947 05 057	947 05 057

Attention: Please always give full description, part no. and quantity of parts required.

This list
consists of
3 pages

FLUX-GERÄTE GMBH D-75433 Maulbronn

Rights reserved to
make alterations
and/or modifications