

PAR™

MODEL 42800-0000 "Loudhailer" Electronic Megaphone

PRODUCT DATA

MODEL 42800-0000



SPECIFICATIONS

Power Output:	15 watts (rated) 20 watts (maximum)
Power Requirements:	8 type "C" batteries
Sound Output:	114 db. at 5 feet
Range:	Approx. 300 meters, depending on environmental conditions
Microphone:	Noise cancel type (built-in)
Dimensions:	1 1/4" Horn Diameter (280 mm) 14 1/8" long (356 mm)
Weight:	Approx. 4 1/4 lbs. (1.9 kg.)

BATTERY INSTALLATION

1. Pull up the catch on the top and open the battery compartment cover.
2. Insert 8 type "C" batteries into the plastic battery holder. Be sure to observe the battery polarity as indicated in the battery compartment.
3. Alkaline batteries are recommended for extra long life.

OPERATION

1. Press the trigger switch on the grip and hold the microphone about 1" from your mouth and speak in a normal voice.
2. Adjust the volume control to the desired level of sound. DO NOT set the volume control too high or it will result in feedback (howling). Use the setting which gives the best level of sound.
3. To turn the loudhailer off, release the trigger switch. To conserve battery life, press the trigger switch sparingly. When not in use, release the trigger.

MAINTENANCE

Never leave weak or dead batteries in your loudhailer; even leakproof types can leak dangerous chemicals. Also, if loudhailer is not to be used for several weeks, remove the batteries.

ITT JABSCO

MARC Division
International Telephone and Telegraph Corporation
1485 Dale Way, Costa Mesa, California 92626
Telephone: (714) 545-8251