



| | | | | | | |
|------|------|----------------|--------------|----------|-----------|-------------|
| 22 | 4 | Washer | Bricka | | | 05-02-101 |
| 21 | 4 | Screw | Skruv | | | 05-04-128 |
| 20 | 5 | Screw | Skruv | | | 05-04-46 |
| 19 | 1 | Screw | Skruv | | | See table |
| 18 | 2 | Plug | Plugg | | | 05-03-122 |
| 17 | 1 | Key | Nil | | | 05-03-124 |
| 16 | 2 | Retaining ring | Låsring | | | 05-34-108 |
| 15 | 1 | Retaining ring | Låsring | | | 05-34-118 |
| 14 | 2 | Ball bearing | Kullager | | | 05-08-504 |
| 13 | 1 | Mech. seal | Mek. tätning | | | 05-20-118 |
| 12 | 1 | V-ring | V-ring | | | 05-19-505 |
| 11 | 1 | Lip seal | Läpp tätning | | | 05-29-118 |
| 10 | 1 | Spacer | Distans | | | 01-42747 |
| 9 | 1 | Pedestal | Lagerfot | | | 01-13020 |
| 8 | 1 | Wear plate | Slitbricka | | | 01-42426 |
| 7 | 1 | Pin | Stift | | | 01-42424 |
| 6 | 1 | Gasket | Packning | | | See table |
| 5 | 1 | Impeller | Impeller | | | See table |
| 4 | 1 | Cam | Kam | | | See table |
| 3 | 1 | Shaft | Axel | | | 01-35137 |
| 2 | 1 | End cover | Lock | | | 01-42422-1 |
| 1 | 1 | Body | Pumphus | | | See table |
| Pos. | Qty. | Description | Benämning | Material | Dimension | Drawing nr. |

| PUMP NO | PUMP TYPE | DESCRIPTION | THICKNESS | NR | SCREW | IMPELLER | BODY | THREAD |
|----------------|-----------|-------------|-----------|----------|-----------|----------|-----------|---------|
| PUMP REPAIRING | PUMPTYP | BENÄMNING | TJOCKLEK | NR | SÄRV | IMPELLER | PUMPHUS | LAGNING |
| 0-13026-1 | F9B-3000 | V1 | 8 | 01-43137 | 05-04-108 | 08-802 B | 0-11358-1 | R 7" |
| 0-13026-2 | F9B-3000 | V2 | 5,2 | 01-43138 | 05-04-127 | 08-804 B | 0-11358-1 | R 7" |
| 0-13026-3 | F9B-3000 | V3 | 8 | 01-43137 | 05-04-108 | 08-804 B | 0-11358-1 | R 7" |
| 0-13026-4 | F9B-3000 | V4 | 5,2 | 01-43138 | 05-04-127 | 08-804 B | 0-11358-1 | R 7" |
| 0-13026-5 | F9B-3000 | V5 | 8 | 01-43137 | 05-04-108 | 08-802 B | 0-11358-2 | R 7" |
| 0-13026-6 | F9B-3000 | V6 | 5,2 | 01-43138 | 05-04-127 | 08-802 B | 0-11358-2 | R 7" |
| 0-13026-7 | F9B-3000 | V7 | 8 | 01-43137 | 05-04-108 | 08-804 B | 0-11358-2 | R 7" |
| 0-13026-8 | F9B-3007 | V8 | 5,3 | 01-43135 | 05-04-107 | 08-814 E | 0-11358-2 | R 7" |
| 0-13026-9 | F9B-3007 | V9 | 2 | 01-43136 | 05-04-108 | 08-814 E | 0-11358-2 | R 7" |
| 0-13026-10 | F9B-3007 | V10 | 5,3 | 01-43135 | 05-04-107 | 08-814 E | 0-11358-2 | R 7" |
| 0-13026-11 | F9B-3007 | V11 | 5,3 | 01-43135 | 05-04-107 | 08-814 E | 0-11358-2 | R 7" |
| 0-13026-12 | F9B-3027 | V12 | 4 | 01-43138 | 05-04-307 | 08-814 E | 0-11358-2 | R 7" |

| | | | | | |
|---|-----------|-----|-----------|--------|-----|
| 4 | 05-04-46 | 087 | 05-04-148 | 031025 | 4,5 |
| 3 | 05-04-128 | 1 | 05-04-128 | 031025 | 4,5 |
| 2 | 05-04-128 | 1 | 05-04-128 | 031025 | 4,5 |
| 1 | 05-04-128 | 1 | 05-04-128 | 031025 | 4,5 |

Multipurpose