



Repair Parts List

Key no.	Part Name	Part no
S1	Strainer	119.000.251
S2	Basket	119.000.250
S3	Gasket	116.000.209
S5	Cover	189.001.133
S6	Knob	119.000.286
S7	Gasket	116.000.216
S9	Stud	105.000.340

Install with other pumps using an optional flange fitting.

The 20915 strainer has the inlet at the top and the outlet at the bottom. This design assures the pump will have a source of water if the strainer is only one half full of water. Prevents pump air locks.

Includes:

- Bronze Body
- Nylon Filter Basket – 1/4 inch Mesh
- Heavy Clear Acrylic Cover and O-ring

The 20915 strainer is easily cleaned. The sea strainer has a big wide opening to facilitate easy removal of the basket.

Mount strainer base with four 1/4 inch screws.

A flexible connector should be used in the suction line between the strainer and the seacock. Outlet flange matches to strainer flange. Limit flow to 140 GPM

Strainer Body

Item Number	Inlet to Strainer	Outlet to Pump
915.150.000	1.5 Female NPT	Flange Pump 376, 377
915.150.150M	1.5 Female NPT	1.5 Male NPT
915.150.125M	1.5 Female NPT	1.25 Male NPT
915.200.000	2.0 Female NPT	Flange Pump 376, 377
915.200.200M	2.0 Female NPT	2.0 Male NPT
915.200.150M	2.0 Female NPT	1.5 Male NPT

The flange fitting is included with NPT outlet to pump selections.