



<b>00LE Pump</b>		
<b>Item</b>	<b>Part Number</b>	<b>Description</b>
1	P100-21-H	screw (LE) (8)
	P105-77-H	screw (RLE) (8)
2	00L6	cover assembly (LE)
	1M31	pin
3	0B34-.002	gasket (LE)
	0B34-.005	gasket (LE)
	0B34-.001	gasket (LEH)
	0B34-.005	gasket (LEH)
	0B34-MX429	gasket (RLE)
4	00B32-1	idler gear (LE)
	00B32	idler gear (LEH)
5	0RLE20	housing (LE)
	0RLEV20-RH	housing (LEV)
	0RLEV2--LH	housing (LEV)
15	00LE24	rotor (LE/LEH))
	00RLE24	rotor (RLE)
15a	00LE24-A	modification "A" rotor
	00RLE24-A	modification "A" rotor
16	P206-34	retaining ring
17	1LA71	bushing
18	1LA9-7	standard Viton seal
	1LA9-5	optional Neoprene seal
	1LA9-8	optional EPR seal
19	P701-34-77	standard Viton O ring
	P701-34-57	optional Neoprene O ring
	P701-34-87	optional EPR O ring
20	1LA11	housing plug (LE)

<b>00LE Relief Valve Option</b>		
<b>Item</b>	<b>Part Number</b>	<b>Description</b>
6	0LV58-X201	plunger
7	0LWV63	standard spring (55-120)
	0C62-X201	optional spring (25-34)
	0C62-X299	optional spring (35-54)
	0LWVH63	optional spring (121-169)
	0LPV63	optional spring (170-374)
	0LV63X	optional spring (375-500)
8	30EN92	retainer
9	P103-11	adjusting screw
10	30F64-X201	valve cap gasket
11	0LWV56	valve cap gasket
12	30LE64-A	cap cover gasket
13	30LE528	nut
14	30LE56	acorn nut

<b>00LE Ball Bearing Option</b>		
<b>Item</b>	<b>Part Number</b>	<b>Description</b>
20a	1LAK37	housing plug (LEK)
20b	0LK511-E	ball bearing (LEK)