



ITEM NO.	PART NUMBER	QTY	DESCRIPTION	MATERIAL
1	1	1	COVER SUB-ASSEMBLY	CAST IRON & STEEL
2	1	1	ROTOR SUB-ASSEMBLY	CAST IRON & BRONZE
3	1	1	BRACKET SUB-ASSEMBLY	CAST IRON & BRONZE
4	1	1	SEAL O-RING	SEAL
5	1	1	SEAL O-RING	SEAL
6	1	1	SEAL O-RING	SEAL
7	1	1	SEAL O-RING	SEAL
8	1	1	SEAL O-RING	SEAL
9	1	1	SEAL O-RING	SEAL
10	1	1	SEAL O-RING	SEAL
11	1	1	SEAL O-RING	SEAL
12	1	1	SEAL O-RING	SEAL
13	1	1	SEAL O-RING	SEAL
14	1	1	SEAL O-RING	SEAL
15	1	1	SEAL O-RING	SEAL
16	1	1	SEAL O-RING	SEAL
17	1	1	SEAL O-RING	SEAL

