





Item No.	Qty. per unit	Description	Part No.	Part No.
		Version according to exploded view No. 001 86 162 – 07/2010		
		Filling unit optionally with or without Start/Stop button cpl. (Item 1 – 6)		
	1	Start/Stop button cpl. (Item 1 – 6)	936 01 007	
1	1	Sealing cap	947 05 017	
2	1	Start/Stop button	936 01 001	
3	2	Screw	902 25 000	
4	1	Support for Start/Stop button	936 01 008	
5	1	Cable gland	947 12 016	
6	1	Holding plate	936 01 009	
7	1	Housing	001 12 437	
8	1	Plug screw	901 00 006	
9	1	Grooved pin	914 74 007	
10	1	Cylindrical pin	914 89 002	
11	1	Bracket	001 12 245	
	1	Stop valve (Item 12 – 18)	959 14 049	
12	1	Reducing piece	959 06 201	
13	1	Cap nut	906 84 010	
14	1	Pressure spring	926 07 007	
15	1	Valve guide	959 14 055	
16	1	Valve housing	959 14 052	
17	1	Valve	959 14 058	
18	1	O-ring Ø 14,5 x 3 (FKM)	925 25 019	
19	1	O-ring Ø 22 x 2 (FKM)	925 45 006	

Attention! Please always give full description, part no. and quantity of parts required.