



Figure 21
Unloader Assembly Items

Ref. No.	Part No.	Description	Qty.
1 ¹	Repair Kit Item	Washer	1
2 ¹	Repair Kit Item	O-ring	1
3 ¹	1720-0186	O-ring	1
4 ¹	Repair Kit Item	O-ring	1
5 ¹	Repair Kit Item	Washer	1
6 ¹	1720-0196	O-ring	1
7 ¹	1720-0163	O-ring	1
8 ¹	3210-0080	Valve Seat	1
9 ¹	1720-0190	O-ring	1
10 ¹	3320-0035	Piston	1
11 ¹	1900-0161	Spring	1
12 ¹	Repair Kit Item	O-ring	1
13 ¹	Repair Kit Item	O-ring	1
14	9900-38FPB	Quick Disconnect (Male End)	1
15	3430-0487	Bolt Kit Assembly (BSP)	1

¹ Denotes Parts Kit items. Parts Kit No. 3430-0484