


# JABSCO®

ACCESSORIES

## MODEL 45838-0000 RUBBER-TIRED MOUNTING CART



### PRODUCT DATA

### SPECIFICATIONS

LENGTH	—	33 IN.	(83,8 cm.)
WIDTH	—	16¾ IN.	(41,5 cm.)
HEIGHT	—	28 IN.	(71,1 cm.)
WEIGHT	—	20 LBS.	(9.1 Kgs)
BASE PLATE	—	ZINC PLATED STEEL	
HANDLE	—	ALUMINUM TUBING	
WHEELS	—	RUBBER TIRED, PLASTIC HUBS.	

MODEL 45838-0000

### SUITABLE FOR THE FOLLOWING PUMPS

SELF PRIMING CENTRIFUGALS — MODEL 45840-0000  
— MODEL 45850-0000  
— MODEL 45860-0000


#### SELF PRIMING, FLEXIBLE IMPELLER PUMPS

GASOLINE — MODEL 6850-0001  
ELECTRIC — MODEL 6050-0001  
WASTE PUMP-OUT — MODEL 6050-0713  
EPOXY PLASTIC CENTRIFUGALS — MODEL 17640-2001  
— MODEL 17640-2007  
— MODEL 17640-2013

**NOTE: ALL WIRING OF CART MOUNTED ELECTRIC UNITS SHOULD BE PERFORMED BY LICENSED ELECTRICIAN, IN ACCORDANCE WITH LOCAL ELECTRICAL CODES. IT IS RECOMMENDED THAT A GROUND FAULT INTERRUPTOR BE USED.**

**ITT JABSCO**

FORM 43000-0427 Rev. 11/81



## ASSEMBLY INSTRUCTIONS

1. Remove burrs from holes and tubing ends with burr knife.
2. Insert handle into arms, aligning holes, and secure with bolts and locknuts.
3. Align holes in lower arms with smaller sets of two holes in base plate skirt. Secure with bolts, lockwashers and nuts.
4. Position foot bracket between arms on bottom of base plate. Secure with bolts, lockwashers and nuts.
5. If cart is to be used in a marine environment, you may wish to paint the assembly at this stage, to protect it from corrosion.
6. Slide axle thru holes in base plate skirt. Place 1 large washer over axle, next to base plate skirt. Install wheels on axle, with molded spokes on inside. Slip large washer onto axle against wheel. Insert cotter pins into holes in axle and bend tabs to secure. Press hub caps into wheel hub recess.

**ITT JABSCO**

MARC Division

International Telephone and Telegraph Corporation  
1485 Dale Way, Costa Mesa, California 92626

Telephone: (714) 545-8251