



Pump No.	Pump type	Shaft	Descr.	Kam / Cam	Screw	Impeller	Body	Thread	Endcover	Label
			Benämning	Thickess / Tjocklek	No. / Nr.	No. / Nr.	Pumphus	Gänga	Lock	Märkskylt
10-24073-1	F5B-8		1/1	4.9	01-42397 05-04-117	08-10278	01-24067-1	R 3/4"	01-42398	
-2	F5B-802		1/2	3.1	01-45014 05-04-173	08-10278-9				
-3	F5B-89		1/1	4.9	01-42397 05-04-117					
-4	F5B-892		1/2	3.1	01-45014 05-04-173					
-5	F5B-8007	01-45045	1/1	4.9	01-42397 05-04-117	08-10278		3/4"-14 NPTF		
-6	F5B-8027		1/2	3.1	01-45014 05-04-173					
-7	F5B-8907		1/1	4.9	01-42397 05-04-117					
-8	F5B-8927		1/2	3.1	01-45014 05-04-173					
-9	F5B-8		1/1	4.9	01-42397 05-04-117	08-10278		R 3/4"	01-46007	01-35302-1
-10	F5B-8007	01-46099	1/1	4.9	01-42397 05-04-117	08-10278		3/4" NPTF	01-42398	
-11	F5B-802	01-45045	1/2	3.1	01-45014 05-04-173			R 3/4"		
-51	F5B-8007	01-46417	1/1	4.9	01-42397 05-04-117	08-10278		3/4"-14 NPTF	01-42398	

Part No.	Part Name	Material	Dimension	Ann. of. no. nr.
17	Märkskylt - Label			See table
16	Låsring - Retaining ring			S9.4 17 05-34-21
15	Låsring - Retaining ring			S9.4 20 05-34-20
14	Kollager - Ballbearing			6203 2 RS 05-09-28
13	O-ring			15.3-2.4 05-06-507
12	Lådaröring - Lipsteel			0.55M 16287 See table
11	Skruv - Screw			M4x8 08-04-642
10	Skruv - Screw			Gummificka - Washer 01-45046
9	Gummificka - Washer			01-45047
8	Bricka - Washer			01-45046
7	Bricka - Washer			See table
6	Kam - Cam			See table
5	Packning - Gasket			See table
4	Impeller			See table
3	Lock - Endcover			See table
2	Axel - Shaft			See table
1	Pumphus - Body			See table

Form nr	Arbetsstätt	Verkst.	Material	Dimension	Ann. of. no. nr.
1	10-24073-1	10-24073-1	Röd	3.2.1976	
2	10-24073-1	10-24073-1	Stål		

Form nr	Arbetsstätt	Verkst.	Material	Dimension	Ann. of. no. nr.
1	10-24073-1	10-24073-1	Röd	3.2.1976	
2	10-24073-1	10-24073-1	Stål		

Pump No.	Mark on endcover	Impeller type + No. 1 weekly code	Gasket, Packing
10-24073-1/8-10			
10-24073-4			01-42401
10-24073-11			01-45933

Note: Label 01-35302-1 is to be placed in centre of endcover 01-46007