

PAR REPLACEMENT PARTS

34600 AND 36600 SERIES

34600-SERIES
(Was 4600 J)

• Indicates items included in Hardware Kit (Key 21)

36600-SERIES
(Was 6600 J)

• Indicates items included in Hardware Kit (Key 21)

Description	Key	34600-Series		36600-Series	
		Part Number	Qty	Part Number	Qty
Motor Kit	12 Volt D.C. 24 Volt D.C. 32 Volt D.C. 115 vac	1	30200-0000	1	30200-0000
			30200-0010		30200-0010
			30200-0020		30200-0020
			30200-0050		30200-0050
Motor Mount	2	34628-0000	1	34628-0000	1
Small Pulley	3	37169-0000	1	37169-0000	1
Large Pulley	4	37170-0001	1	37171-0001	1
Belt	5	30021-0000	• 1	30022-0000	• 1
Jack Shaft Assembly	6	35037-0001	1	35691-0001	1
Connecting Rod Assembly	7	37172-0001	1	37173-0001	1
Old Style w/Allen Screw Drive	1	37172-0000	1	37173-0000	
Diaphragm Plates	8	Top: 34640-0000 Bottom: 34627-0000	1	35212-0000	2
Diaphragm	9	30012-0000	• 1	30016-0000	• 1
Retainer	10	Top: 34633-0000 Bottom: 34634-0000	1	35173-0000	1
Valve Set (Inlet & Outlet)	11	30002-0000	• † 1 set	30003-0000	• † 1 set
Base Assembly †	12	34623-0000	† 1	35630-1100	† 1
Ports (Inlet & Outlet)	13	—		37175-0000	† 1
Small Pulsation Dampener	14	—		37177-0000	• † 1
Pulsation Dampener	15	—		37178-0000	• † 1
Small Bottom Plate	16	—		35628-0000	† 1
Bottom Plate	17	—		35623-0000	† 1
Surge Chamber	18	34635-0000	1	—	
Gaskets	19	37181-0000	† 1 set	—	
Vibration Pad Kit	20	37180-0000	1 set	37180-0000	† 1 set
Hardware Kit	21	37164-0001	1 set	37165-0001	1 set
Service Kit*		30101-0000	•	30124-0000	•

• Indicates parts contained in service kits.

36680 AND 36960 SERIES

36680-SERIES
(Was 6680 J / 6685 J)

• Indicates items included in Hardware Kit (Key 21)

36960-SERIES
(Was 6960 J)

• Indicates items included in Hardware Kit (Key 21)

Description	Key	36680-Series				36960-Series				
		Part Number	Series Qty (1000)	Series Qty (2000)	Part Number	Series Qty (1000)	Series Qty (2000)			
Motor Kit	12 Volt D.C. 24 Volt D.C. 32 Volt D.C.	1	30200-0000	1	X	X	30202-0000	1	X	X
			30200-0010					30202-0010		
			30200-0020					30202-0020		
Motor Mount	2	34628-0000	1	X	X	35487-0000	1	X	X	
Small Pulley	3	37169-0000	1	X	X	—				
Large Pulley	4	37171-0000	1	X	X	—				
Belt	5	30022-0000	• 1	X	X	—				
Jack Shaft Assembly	6	35690-0002	1	X	X	—				
Connecting Rod Assembly	7	37173-0001	1	X	X	30040-0000	• 1	X	X	
Old Style w/Allen Screw Dr.		37173-0000				—				
Diaphragm Plates	8	35212-0000	2	X	X	35688-0000	2	X	X	
Diaphragm	9	30016-0000	• 1	X	X	30015-0000	• 1	X	X	
Retainer	10	35173-0000	1	X	X	35455-0000	1	X	X	
Valve Set (Inlet & Outlet)	11	30003-0000	• † 1 set	X	X	30003-0000	• † 1 set	X	X	
Base Assembly †	12	35620-0000	† 1	X		35620-0000	† 1	X		
		44114-1000	† 1	X		44114-1000	† 1	X		
Ports (Inlet & Outlet)	13	37175-0000	† 1	X	X	37175-0000	1	X	X	
Small Pulsation Dampener	14	—				—				
Pulsation Dampener	15	37178-0000	• † 1	X		37178-0000	• † 1	X		
		44127-1000		X		44127-1000	†		X	
Small Bottom Plate	16	—				—				
Bottom Plate	17	35686-0000	† 1	X	X	35686-0000	† 1	X	X	
Surge Chamber	18	—				—				
Gaskets	19	—				—				
Vibration Pad Kit	20	37180-0000	† 1 set	X		37180-0000	† 1 set	X		
		43990-0058		X		44990-0058	† 1 set	X		
Hardware Kit	21	37166-0001	1 set	X		37166-0000	1 set	X		
		43990-0071	1 set	X		43990-0060	1 set	X		
Service Kit*		30125-0000	•	X		30120-0000	•	X		
		43990-0062	•	X		43990-0063	•	X		

• Indicates parts contained in service kit.

† Indicates parts supplied with base assembly.

- CONTENTS
- PUMPING PRINCIPLES
- ENGINE COOLING
- ENGINEERING TABLES
- TROUBLE-SHOOTING GUIDE
- INDEX
- HOME
- NEXT
- BACK