



22	4	Washer	Bricka	05-02-101
21	4	Screw	Skruv	05-04-128
20	5	Screw	Skruv	05-04-46
19	1	Screw	Skruv	See table
18	2	Plug	Plugg	05-03-122
17	1	Key	Nil	05-03-124
16	2	Retaining ring	Låsring	05-34-108
15	1	Retaining ring	Låsring	05-34-118
14	2	Ball bearing	Kullager	05-08-504
13	1	Mech. seal	Mek. tätning	05-20-118
12	1	V-ring	V-ring	05-19-505
11	1	Lip seal	Läpp tätning	05-29-118
10	1	Spacer	Distans	01-42747
9	1	Pedestal	Lagerfot	01-13020
8	1	Wear plate	Slitbricka	01-42423
7	1	Pin	Stift	01-42426
6	1	Gasket	Packning	01-42424
5	1	Impeller	Impeller	See table
4	1	Cam	Kam	See table
3	1	Shaft	Axel	01-35137
2	1	End cover	Lock	01-42422-1
1	1	Body	Pumphus	See table
Pos. Qty.	Description	Beaktning	Material	Dimension Drawing nr.

PUMP NO	PUMP TYPE	DESCRIPTION	THICKNESS	NR	SCREW	IMPELLER	BODY	THREAD
PUMPRETERNING	PUMPTYP	BENÄMNING	TJOCKLEK	NR	SÄRUV	IMPELLER	PUMPHUS	LAGRINGS
0-13026-1	F9B-3000	V1	8	01-43137	05-04-108	08-802 B	0-11358-1	R 7"
0-13026-2	F9B-3000	V2	5,2	01-43138	05-04-107	08-802 B	0-11358-1	R 7"
0-13026-3	F9B-3000	V3	8	01-43137	05-04-108	08-802 B	0-11358-1	R 7"
0-13026-4	F9B-3000	V4	5,2	01-43138	05-04-107	08-802 B	0-11358-1	R 7"
0-13026-5	F9B-3000	V5	8	01-43137	05-04-108	08-802 B	0-11358-1	R 7"
0-13026-6	F9B-3000	V6	5,2	01-43138	05-04-107	08-802 B	0-11358-1	R 7"
0-13026-7	F9B-3000	V7	8	01-43137	05-04-108	08-802 B	0-11358-1	R 7"
0-13026-8	F9B-3007	V8	5,3	01-43135	05-04-107	08-802 B	0-11358-2	R 1 1/2"
0-13026-9	F9B-3007	V9	2	01-43136	05-04-108	08-802 B	0-11358-2	R 1 1/2"
0-13026-10	F9B-3007	V10	5,3	01-43135	05-04-107	08-802 B	0-11358-2	R 1 1/2"
0-13026-11	F9B-3007	V11	5,3	01-43136	05-04-108	08-802 B	0-11358-2	R 1 1/2"
0-13026-12	F9B-3007	V12	4	01-43138	05-04-107	08-802 B	0-11358-2	R 1 1/2"

4	05-04-46	087	05-04-148	031025	4,5
3	0-13026-7	Am-12	148mm	05-04-107	4,5
2	0-13026-4	128mm	128mm	05-04-108	4,5
1	0-13026-1	128mm	128mm	05-04-107	4,5

Multipurpose