



SELF-PRIMING PUMP

FEATURES

Body: Phenolic

Impeller: Jabsco Neoprene, Nitrile Compound

Shaft Seal: Lip Type

Shaft: Stainless Steel (Supplied in Motor)
Ports: 3/4" External Thread Garden Hose

3/8" Internal Pipe Thread

Weight: 5-3/4 lb (2,6 kg)

Motor: 115 Vac (Intermittent Duty)



STANDARD MODELS

| Model No. | Description |
|------------|-------------------|
| 12310-0001 | Neoprene Impeller |
| 12310-0003 | Nitrile Impeller |



Explosion hazard. Motor can spark. Explosion and death can occur. Do not use where flammable vapors are present.

APPLICATION INFORMATION

Designed as a low cost pump with improved chemical resistance for chemical feeding, transfer, circulation, filtration, metering, filling line use and similar applications. Handles pure solutions, foaming liquids, and thin emulsions.

Because of the chemical, resistance of phenolic plastic and 316 stainless steel, these pumps are widely used to pump photo chemicals, plating solutions, lab solutions, pharmaceuticals, cosmetics, weak acids, alkalies, liquid fertilizers, insecticides, dyes, detergents, waxes and many more.

Limit to liquids with viscosity less than 50 SSU.

See the Jabsco "Chemical Resistance Table" in the Industrial Catalog which has been prepared as a guide to selection of pump material.

OPERATING INSTRUCTIONS

- 1. Installation: Pump may be mounted in any position. The intake is located on the right when looking at the end cover.
- 2. Self-Priming: Pump will produce suction lifts up to 7 feet when dry and to 15 feet when wetted. Be sure suction lines are airtight or pump will not self-prime.

- 3. Running Dry: Unit depends on liquid pumped for lubrication. Do Not Run Dry for more than 30 seconds. Lack of liquid will damage the impeller and the plastic pump components.
- 4. Notice: If pumping light fraction petroleum derivatives, solvents, thinners, highly concentrated or organic acids, consult Jabsco Chemical Resistance Table (which is available upon request from ITT Jabsco) for proper body materials and impeller compounds. If corrosive fluids are handled, pump life will be prolonged if pump is flushed with water after each use or after each work day.
- 5. Pressures: Consult Head Capacity Table for recommended maximum for continuous operation. If pressures exceed those shown, consult the factory.
- 6. Temperatures: Neoprene 45°-180°F, Nitrile 50°-180°F.
- Spare Parts: A spare service kit should be kept on hand to eliminate excessive downtime.


HEAD CAPACITY TABLE

Total Head Capacity

| psi Min. | Kg. per Sq.Cm | Feet of Water | Meters of Water | GPM | Liters Per |
|-------------|------------------|------------------|--------------------|-----|---------------|
| 4.3 | 0,3 | 10 | 3,0 | 4.0 | 15,1 |
| 8.7 | 0,6 | 20 | 6,1 | 3.5 | 13,2 |
| 13.0 | 0,9 | 30 | 9,1 | 3.0 | 11,4 |
| 17.3 | 1,2 | 40 | 12,2 | 2.5 | 9,5 |

Flow rates are for water, capacity may be slightly reduced when handling heavy solids. Full load Amps – 7.2


Model 12310-Series



PARTS LIST

| | | | Model12310-0001 |
|-----|--------------------------------|-----------|-----------------|
| Key | Description | Qty. Req. | Part Number |
| 1 | Screw (End Cover) | 2 | 91023-0050 |
| 2 | Body | 1 | 12375-0000 |
| 3 | *Impeller (Neoprene) | 1 | 14792-0001 |
| | *Impeller (Nitrile) | 1 | 14792-0003 |
| 4 | *O-Ring | 1 | 92000-0750 |
| 5 | Seal Housing | 1 | 12314-0000 |
| 6 | *Seal Assembly | 1 | 1040-0000 |
| 7 | Slinger | 1 | 6342-0000 |
| 8 | Motor | 1 | 9195-0004 |
| 9 | Grommet | 4 | 92900-0120 |
| | Replacement Pump Head | | 12377-0001 |
| | Service Kit Neoprene | | 90158-0011 |
| | Service Kit Nitrile | | 90158-0033 |
| | Brush Assembly Replacement Kit | | 42626-0001 |

^{*}Parts supplied in Service Kit



SERVICE INSTRUCTIONS

DISASSEMBLY

- 1.Remove screws, body, O-ring and seal housing.
- 2. Withdraw impeller.
- 3.Deform seal and remove from seal housing.

NOTE: Do not tamper with or disassemble motor.

ASSEMBLY

- Lubricate seal. Deform seal and install in cavity with open side of seal facing impeller.
- 2.Lubricate motor shaft and install seal housing on motor.

INSPECTION UPON REQUEST.

3. Lubricate impeller bore and, aligning flat in impeller with flat on motor shaft, install impeller.

THE PRODUCTS DESCRIBED HEREIN ARE

Form: 43000-0025

SUBJECT TO THE JABSCO ONE YEAR LIMITED

WARRANTY, WHICH IS AVAILABLE FOR YOUR

4.Install O-ring, body and screws.

Jabsco





Jabsco 1485 Dale Way, P.O. Box 2158 Costa Mesa, CA 92628-2158 Tel: (714) 545-8251 Fax: (714) 957-0609 UNITED KINGDOM Jabsco Bingley Road, Hoddesdon Hertfordshire EN11 OBU Tel: +44 (0) 1992 450145 Fax: +44 (0) 1992 467132 CANADA Fluid Products Canada 55 Royal Road Guelph, Ontario N1H 1T1 Tel: (519) 821 -1900 Fax: (519) 821-2569 JAPAN NHK Jabsco Company Ltd. 3-21-10, Shin-Yokohama Kohoku-Ku, Yokohama, 222 Tel: 045-4758906

Fax: 045-475-8908

GERMANY Jabsco GmbH Oststrasse 28 22844 Norderstedt Tel: +49-40-53 53 73 -0 Fax: +49-40-53 53 73 -11

CERT

ISO 9001 QUALITY SYSTEM