

Model 12310-SERIES



SELF-PRIMING PUMP **FEATURES**

Body: Phenolic

Impeller: Jabsco Neoprene, NitrileCompound

Shaft Seal:

Shaft: Stainless Steel (Supplied in Motor) 3/4" External Thread Garden Hose Ports:

3/8" Internal Pipe Thread

Weight: 5-3/4 lbs (2,6kg)

Motor: 115 Vac (Intermittent Duty)

STANDARD MODELS

| MODEL NO. | DESCRIPTION | |
|------------|-------------------|--|
| 12310-0001 | Neoprene Impeller | |
| 12310-0003 | Nitrile Impeller | |



APPLICATION INFORMATION

Designed as a low cost pump with improved chemical resistance for chemical feeding, transfer, circulation, filtration, metering, filling line use and similar. Handles pure solutions, foaming liquids, and thin emulsions.

Because of the chemical resistance of phenolic plastic and 316 stainless steel these pumps are widely used to pump photo chemicals, plating solutions, lab solutions, pharmaceuticals, cosmetics, weak acids, alkalies, liquid fertilizers, insecticides, dyes, detergents, waxes and many more.

Limit to liquids with viscosity less than 50 SSU.

See the Jabsco "Chemical Resistance Table" in the Industrial Catalog which has been prepared as a guide to selection of pump material.

OPERATING INSTRUCTIONS


- 1. INSTALLATION Pump may be mounted in any position. The intake is located on the right when looking at the end cover.
- 2. SELF-PRIMING Pump will produce suction lifts up to 10 feet when dry and to 15 feet when wetted. BE SURE SUCTION LINES ARE AIRTIGHT OR PUMP WILL NOT SELF-PRIME.
- 3. RUNNING DRY Unit depends on liquid pumped for lubrication. DO NOT RUN DRY FOR MORE THAN 30 SECONDS. Lack of liquid will damage the impeller and the plastic pump components.

- 4. NOTICE If pumping light fraction petroleum derivatives, solvents, thinners, highly concentrated or organic acids, consult Jabsco Chemical Resistance Table (which is available upon request from ITT Jabsco) for proper body materials and impeller compounds. If corrosive fluids are handled, pump life will be prolonged if pump is flushed with water after each use or after each work day.
- 5. PRESSURES Consult Head Capacity Table for recommended maximum for continuous operation. If pressures exceed those shown, consult the factory.
- 6. TEMPERATURES Neoprene 45°-180°F, Nitrile 50°-180°F.
- 7. SPARE PARTS: A spare service kit should be kept on hand to eliminate excessive downtime.

HEAD CAPACITY TABLES

Total Head Capacity


| PSI | Kg. per Sq.Cm | Feet of Water | Metres of Water | GPM | Litres Per Min. |
|------|------------------|------------------|--------------------|-----|--------------------|
| 4.3 | 0,3 | 10 | 3,0 | 4.0 | 15,1 |
| 8.7 | 0,6 | 20 | 6,1 | 3.5 | 13,2 |
| 13.0 | 0,9 | 30 | 9,1 | 3.0 | 11,4 |
| 17.3 | 1,2 | 40 | 12,2 | 2.5 | 9,5 |



PARTS LIST

| Key | Description | Qty. Req. | Model 12310-0001 Part Number |
|-----|--------------------------------|-----------|---------------------------------|
| 1 | Screw (End Cover) | 2 | 91023-0050 |
| 2 | Body | 1 | 12375-0000 |
| 3 | *Impeller (Neoprene) | 1 | 14792-0001 |
| | *Impeller (Nitrile) | 1 | 14792-0003 |
| 4 | *O-Ring | 1 | 92000-0750 |
| 5 | Seal Housing | 1 | 12314-0000 |
| 6 | *Seal Assembly | | 1040-0000 |
| 7 | Slinger | 1 | 6342-0000 |
| 8 | Motor | 1 | 9195-0004 |
| | Grommet | 4 | 92900-0120 |
| | Replacement Pump Head | | 12377-0001 |
| | Service Kit Neoprene | | 90158-0011 |
| | Service Kit Nitrile | | 90158-0033 |
| | Brush Assembly Replacement Kit | | 42626-0000 |

*Parts supplied in Service Kit



THE PRODUCTS DESCRIBED HEREIN ARE SUBJECT TO THE JABSCO ONE YEAR LIMITED WARRANTY, WHICH IS AVAILABLE FOR YOUR INSPECTION UPON REQUEST.

SERVICE INSTRUCTIONS

Disassembly

- 1. Remove screws, body, O-ring and seal housing.
- 2. Withdraw impeller.
- 3. Deform seal and remove from seal housing.

NOTE: Do no tamper with or disassemble motor.

Assembly

- Lubricate seal. Deform seal and install in cavity with open side of seal facing impeller.
- 2. Lubricate motor shaft and install seal housing on motor.
- Lubricate impeller bore and, aligning flat in impeller with flat on motor shaft, install impeller.
- 4. Install O-ring, body and screws.

ITT JABSCO

A Unit of ITT Corporation 1485 Dale Way, P.O. Box 2158 Costa Mesa, California 92628-2158 Telephone: (714) 545-8251 Form 43000-0025 Rev. 12/89